



Operation manual

PRO bath thermostats and circulation thermostats

P 10, P 20, P 30, RP 3035, RP 2040, RP 2045, RP 1090, RP 2090, RP 10100, RP 240 E, RP 245 E, RP 250 E,
RP 290 E, P 2 E
with Base remote control



V04REV15

Read this manual prior to performing any task!

°FAHRENHEIT. °CELSIUS. °LAUDA.

LAUDA DR. R. WOBSE GMBH & CO. KG

Pfarrstraße 41/43

97922 Lauda-Königshofen

Germany

Tel.: +49 (0)9343 503-0

Fax: +49 (0)9343 503-222

E-mail: info@lauda.de

Internet: www.lauda.de

Translation of the original operation manual

YACD0102, 4, en_US © LAUDA 2015

replaces issue V04R14, V04R13, V04R07, V4R04, V03REV30-29-28-16, V2RE4, V2R03, V1R54, V01R52, V01R48, V01R35

6/6/2019

Table of contents

| | | |
|----------|--|-----------|
| 1 | Safety..... | 7 |
| 1.1 | Safety structure of the devices..... | 7 |
| 1.2 | EMC requirements..... | 7 |
| 1.3 | Software versions..... | 8 |
| 1.4 | Observing additional operating instructions..... | 9 |
| 1.5 | Intended use..... | 9 |
| 1.6 | Foreseeable misuse..... | 9 |
| 1.7 | Prohibition of modifications to the device..... | 10 |
| 1.8 | Materials..... | 10 |
| 1.9 | Fluorinated refrigerant..... | 10 |
| 1.10 | Natural refrigerant..... | 10 |
| 1.11 | Heat transfer liquid requirements..... | 11 |
| 1.12 | Hose requirements..... | 11 |
| 1.13 | Application area..... | 11 |
| 1.14 | Personnel qualification..... | 11 |
| 1.15 | Personal protective equipment..... | 11 |
| 1.16 | Personal protective equipment..... | 12 |
| 1.17 | Safety fittings on the device..... | 12 |
| | 1.17.1 Overtemperature protection..... | 12 |
| | 1.17.2 Low-level protection..... | 12 |
| 1.18 | Warning symbols on the device..... | 12 |
| 1.19 | Structure of warnings..... | 13 |
| 2 | Unpacking..... | 15 |
| 3 | Structure and function..... | 17 |
| 3.1 | Structure..... | 17 |
| | 3.1.1 Structure of the bath thermostat..... | 17 |
| | 3.1.2 Structure of the circulation thermostats..... | 19 |
| 3.2 | Operating elements..... | 22 |
| | 3.2.1 Mains and safety switch..... | 22 |
| | 3.2.2 Release button and maximum temperature knob..... | 23 |
| 3.3 | Functional elements..... | 23 |
| | 3.3.1 Hydraulic circuit..... | 23 |
| | 3.3.2 Refrigerating machine..... | 25 |
| | 3.3.3 Heat discharge through cooling in a hybrid design..... | 26 |
| | 3.3.4 Nitrogen overlay..... | 26 |
| | 3.3.5 Series standard and optional interfaces..... | 27 |
| | 3.3.6 Type plate..... | 29 |

| | | |
|----------|---|-----------|
| 4 | Before starting up..... | 30 |
| 4.1 | Installation..... | 30 |
| 4.2 | Installing interface modules..... | 31 |
| 4.3 | RS 232 interface..... | 32 |
| 4.3.1 | Cable and test of the RS 232 interface..... | 32 |
| 4.3.2 | Protocol RS 232..... | 33 |
| 4.3.3 | Connecting cable RS 485..... | 34 |
| 4.3.4 | Protocol RS 485..... | 34 |
| 4.4 | Ethernet interface..... | 35 |
| 4.4.1 | Connections via the Ethernet interface..... | 35 |
| 4.4.2 | Configuring the Ethernet interface..... | 37 |
| 4.4.3 | Data transfer rate..... | 43 |
| 4.4.4 | Protocol of the interface..... | 44 |
| 4.5 | Read and write errors on the interfaces..... | 44 |
| 4.5.1 | Write commands of the interface..... | 44 |
| 4.5.2 | Read commands of the interface..... | 46 |
| 4.5.3 | Error messages from the thermostatic circulator to the control station..... | 49 |
| 4.6 | Setting up the circulation thermostat..... | 50 |
| 4.7 | Racks, platforms, rising platforms..... | 50 |
| 4.8 | External consuming unit..... | 51 |
| 4.8.1 | Hoses..... | 51 |
| 4.8.2 | Connecting an external consuming unit..... | 53 |
| 4.9 | Cooling water..... | 55 |
| 4.9.1 | Cooling water requirements..... | 55 |
| 4.9.2 | Connecting the cooling water..... | 57 |
| 5 | Commissioning..... | 59 |
| 5.1 | LAUDA heat transfer liquids..... | 59 |
| 5.2 | Filling the device..... | 61 |
| 5.3 | Changing/draining heat transfer liquid..... | 64 |
| 5.4 | Establishing a mains connection..... | 65 |
| 5.5 | Switching on the device..... | 66 |
| 5.6 | Display buttons..... | 66 |
| 5.7 | Base remote control unit menu structure..... | 68 |
| 5.8 | Setting overtemperature protection T_{max} | 69 |
| 5.9 | Setting temperature limits T_{ih} and T_{il} | 70 |
| 5.10 | Setting the temperature target value T_{set} | 71 |
| 5.11 | Basic settings..... | 71 |
| 5.11.1 | Safety Mode..... | 71 |
| 5.11.2 | Adjusting the volume of signal tones..... | 74 |

| | | |
|----------|---|------------|
| 5.11.3 | Adjusting the display brightness..... | 75 |
| 5.11.4 | Operating mode following a power failure (auto start)..... | 75 |
| 5.11.5 | Limiting the current consumption..... | 76 |
| 5.11.6 | Selecting the menu language..... | 76 |
| 6 | Operation..... | 77 |
| 6.1 | General safety instructions..... | 77 |
| 6.2 | Operating modes..... | 79 |
| 6.3 | Setting the pump level..... | 79 |
| 6.4 | Activating and deactivating standby and operation modes..... | 79 |
| 6.5 | Defining the actuating signal limit..... | 80 |
| 6.6 | External control..... | 80 |
| 6.6.1 | Activating external control, deactivating internal control..... | 80 |
| 6.6.2 | Setting the set point offset..... | 81 |
| 6.7 | Programmer..... | 82 |
| 6.7.1 | Basic information..... | 82 |
| 6.7.2 | Starting, interrupting, continuing and ending a program..... | 85 |
| 6.8 | Control parameters..... | 86 |
| 6.8.1 | Control basics..... | 87 |
| 6.8.2 | Overview of internal control parameters..... | 89 |
| 6.8.3 | Overview of external control parameters..... | 90 |
| 6.8.4 | Opening the control menu..... | 91 |
| 6.8.5 | Editing internal control parameters..... | 91 |
| 6.8.6 | Editing external control parameters..... | 92 |
| 6.9 | Calibrating the temperature probe..... | 93 |
| 6.10 | Viewing the device status..... | 95 |
| 7 | Maintenance..... | 97 |
| 7.1 | General safety instructions..... | 97 |
| 7.2 | Maintenance intervals..... | 98 |
| 7.3 | Cleaning the device..... | 98 |
| 7.4 | Cleaning the air-cooled condenser..... | 99 |
| 7.5 | Cleaning the water-cooled condenser..... | 99 |
| 7.6 | Checking the heat transfer liquid..... | 101 |
| 7.7 | Checking the overtemperature protection..... | 101 |
| 7.8 | Checking the low-level protection..... | 102 |
| 8 | Faults..... | 104 |
| 8.1 | Alarms, warnings and errors..... | 104 |
| 8.2 | Alarms..... | 104 |
| 8.3 | Control system warnings..... | 105 |
| 8.4 | Safety system warnings..... | 106 |

| | | |
|-----------|---|------------|
| 8.5 | SmartCool warnings..... | 108 |
| 9 | Decommissioning..... | 110 |
| 9.1 | General information on decommissioning..... | 110 |
| 9.2 | Changing/draining heat transfer liquid..... | 111 |
| 10 | Disposal..... | 112 |
| 10.1 | Disposing of refrigerant..... | 112 |
| 10.2 | Device disposal..... | 112 |
| 10.3 | Disposing of packaging..... | 112 |
| 11 | Technical data..... | 113 |
| 11.1 | General data..... | 113 |
| 11.2 | Refrigerating machine and cooling water..... | 116 |
| 11.3 | Refrigerant and filling weight..... | 119 |
| 11.4 | Maximum current consumption and heating output..... | 121 |
| 12 | Accessories..... | 123 |
| 13 | General..... | 124 |
| 13.1 | Copyright..... | 124 |
| 13.2 | Technical changes..... | 124 |
| 13.3 | Warranty conditions..... | 124 |
| 13.4 | Contact LAUDA..... | 124 |
| 13.5 | EU conformity..... | 124 |
| 14 | Glossary..... | 125 |
| 15 | Index..... | 127 |

1 Safety

1.1 Safety structure of the devices

- The devices can only be operated as intended under the conditions specified in this operating manual. Any other mode of operation is considered to be an unintended use and could compromise the protection warranted by the device.
- The devices are not designed for use in medical applications in accordance with DIN EN 60601-1 and IEC 601-1!
- This operating manual is part of the device. The information in this operating manual must therefore be kept at hand in the immediate vicinity of the device. Be sure to carefully store this copy of the operating manual.



If this operating manual is lost, contact LAUDA Service Constant Temperature Equipment. You will find the contact information here ↪ Chapter 13.4 “Contact LAUDA” on page 124.

When operating the device, there is a risk of injury from high and low temperatures, fire and the presence of electrical energy. These risks posed by the device have been mitigated in the design to the extent possible in keeping with the applicable norms. The remaining risk can be reduced using one of the following measures:

- Safety equipment is available for the device. This equipment is critical to the safety of the device. Appropriate maintenance activities must be implemented to ensure the device remains in good working order.
The safety fittings for the device are described in this "Safety" chapter.
- Various warning symbols are located on the device. These symbols must be observed without fail.
The warning symbols on the device are described in this "Safety" chapter.
- This operating manual contains safety information. This information must be followed at all times.
- Personnel and the protective equipment worn by personnel are also subject to specific requirements.
These requirements are described in this "Safety" chapter.



Refer to ↪ Chapter 1.19 “Structure of warnings” on page 13 for more information on the general structure of safety notices.

1.2 EMC requirements

Table 1: Classification in accordance with EMC requirements

| Device | Immunity | Emissions class | Customer power supply |
|--------------------|--|---|----------------------------|
| Heating thermostat | Type 2 in accordance with DIN EN 61326-1 | Emissions Class B in accordance with CISPR 11 | Worldwide No limitation |

| Device | Immunity | Emissions class | Customer power supply |
|----------------------------|--|---|---|
| Low temperature thermostat | Type 2 in accordance with DIN EN 61326-1 | Emissions Class B in accordance with CISPR 11 | Only for EU Domestic connection value ≥ 100 A |
| Low temperature thermostat | Type 2 in accordance with DIN EN 61326-1 | Emissions Class B in accordance with CISPR 11 | Rest of the world (outside EU) No limitation |

Instructions for Class A digital device, USA

"This equipment has been tested and found to comply with the limits for Class A digital device, pursuant to Part 15 of the FCC (Federal Communication Commission) Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense."

Instructions for Class A digital device, Canada

"This Class A digital apparatus complies with Canadian ICES-003" (ICES = Interference Causing Equipment Standards).

« Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada ».

1.3 Software versions

These operating instructions are valid for devices with the following software versions or higher.

| Software | Valid from version |
|--------------------------------|--------------------|
| Command Touch operating system | 1.14 |
| Base operating system | 1.33 |
| Control system | 1.36 |
| Protection system | 1.25 |
| Cooling system | 1.42 |
| Pump | 1.01 |
| Analog IO module | 3.14 |
| RS 232/485 module | 3.22 |
| Digital IO module | 3.14 |
| Solenoid valve | 3.06 |
| EtherCAT module | 1.06 |

1.4 Observing additional operating instructions

Interface modules

Additional interface modules can be fitted to the device. Before installing and using interface modules, always read and observe the operating manual accompanying the relevant interface module.

1.5 Intended use

This section is relevant for:

- the Bath thermostat device category

As intended

- The bath thermostat (heating and cooling bath thermostats) may only be used to control the temperature of combustible and non-combustible liquids.
- The heating bath thermostat can be operated using the integral cooling coil. As a result, the heating bath thermostat can be used to cool fluids.

Unintended

The following types of use are considered unintended:

- Use as a medical device
- Use in potentially explosive areas
- Use for controlling the temperature of foodstuffs

This section is relevant for:

- the Circulation thermostat device category

As intended

- The circulation thermostat may only be used to recirculate and control the temperature of combustible and non-combustible heat transfer liquids. The heat transfer liquid is pumped through an external circuit incorporating a closed consuming unit back into the thermostat.

Unintended

The following types of use are considered unintended:

- Use as a medical device
- Use in potentially explosive areas
- Use for controlling the temperature of foodstuffs
- Use with a glass reactor without overpressure protection

1.6 Foreseeable misuse

The following are considered cases of foreseeable misuse:

- Operating the device without heat transfer liquid
- Connecting hoses incorrectly
- Setting an incorrect pump pressure

1.7 Prohibition of modifications to the device

Any modification of the device by the user is prohibited. Anything resulting from unauthorized modification is not covered by customer service or the product warranty. Service work may only be performed by LAUDA Service Temperature control devices or a service partner authorized by LAUDA.

1.8 Materials

This section is relevant for:

- the Bath thermostat device category

All parts of the device that come into contact with heat transfer liquid are manufactured from high-quality materials adapted to withstand the operating temperature. The range of materials used includes high-quality stainless steels and high-quality, temperature-resistant plastics.

This section is relevant for:

- the Circulation thermostat device category

All parts of the device that come into contact with heat transfer liquid are manufactured from high-quality materials adapted to withstand the operating temperature. The range of materials used includes high-quality stainless steels, high-quality, temperature-resistant plastics and brass.


1.9 Fluorinated refrigerant

The cooling thermostats are operated with non-odorized refrigerant (fluorinated greenhouse gas), depending on the device model. There are no special installation requirements due to the low refrigerant charge and hermetically sealed design. The designation and refrigerant charge are specified on the type plate.

1.10 Natural refrigerant

Some cooling thermostats are operated with non-odorized natural refrigerant, depending on the device model. These refrigerants are combustible. There are no special installation requirements due to the low refrigerant charge and hermetically sealed design. The designation and refrigerant charge are specified on the type plate.



See information  Further information on page 30

1.11 Heat transfer liquid requirements

- Heat transfer liquids are used to control the temperature. Only LAUDA heat transfer liquids are approved for use in the device. LAUDA heat transfer liquids are liquids that have been tested and approved by LAUDA DR. R. WOBSEER GMBH & CO. KG.
- The device is designed for combustible heat transfer liquids according to class III as per DIN 12876-1.
- The heat transfer liquids are suitable for a specific temperature range. This temperature range must correspond with the temperature range of your application.
- The use of heat transfer liquids poses a risk of injury from high and low temperatures and fire if certain upper or lower temperature thresholds are exceeded or the container is broken, causing a reaction with the heat transfer liquid.
- All possible risks in handling the heat transfer liquid are specified in the safety datasheet for the liquid together with corresponding safety measures. The safety datasheet must therefore be observed in order to use the device as intended.

1.12 Hose requirements

Only LAUDA hoses may be used for the external hydraulic circuit. LAUDA hoses have been approved by LAUDA DR. R. WOBSEER GMBH & CO. KG. Note the permitted temperature range and maximum permitted pressure when selecting suitable hoses for the application.

1.13 Application area

The device may only be used in the following areas.

- Due to national and international safety regulations, the use and transportation of devices containing natural refrigerant is restricted to the 230 V; 50 Hz voltage variant.
- Commercial sector
- Internal areas, not suitable for outdoor installation
- Maximum storage temperature 43 °C (devices containing natural refrigerant)

1.14 Personnel qualification

Operating personnel

Operating personnel are personnel who have been instructed on how to use the device as intended in line with the information in the operating manual.

Specialized personnel

Certain activities on the device must be performed by specialized personnel. Specialized personnel are personnel whose education, knowledge, and experience qualify them to assess the function and risks associated with the device and its use.

1.15 Personal protective equipment

1.16 Personal protective equipment

Protective clothing

Protective clothing must be worn for certain tasks. This protective clothing must meet the legal requirements for personal protective equipment valid in the European Union.

Safety glasses

Safety glasses must be worn for certain tasks. These safety glasses must meet existing legal requirements for personal protective equipment valid in the European Union.

Protective gloves

CE protective gloves must be worn for certain tasks. These protective gloves must meet the legal requirements for personal protective equipment valid in the European Union.

1.17 Safety fittings on the device

1.17.1 Overtemperature protection

The overtemperature protection is a safety unit that prevents combustible heat transfer liquid from igniting due to high temperatures. All safety components on the device are shut down to prevent fire from posing a danger. An alarm signal also indicates that the overtemperature protection has been activated. The temperature at which the safety unit is activated must be set in line with the heat transfer liquid used.

We recommend testing the overtemperature protection at regular intervals.



See ↗ Chapter 7.7 “Checking the overtemperature protection” on page 101 for further information.

1.17.2 Low-level protection

The low-level protection is a safety unit that prevents damage to the device and prevents the hot heater from igniting combustible heat transfer liquid. If the heat transfer liquid level in the device falls below a specified level (level 2), a warning is issued initially. If the level continues to fall (level 1), an alarm is triggered. All safety components on the device are switched off as a result.

We recommend testing the low-level protection at regular intervals.



See ↗ Chapter 7.8 “Checking the low-level protection” on page 102 for further information.

1.18 Warning symbols on the device

Hot



"Hot surface" warning symbols are affixed to the device. This symbol warns against hot surfaces on the device. These surfaces must not be touched during operation. These surfaces must be allowed to cool to room temperature before they can be touched during other operation phases such as servicing.

This section is relevant for:

- devices containing natural refrigerant

Flammable




- The "Flammable" warning symbol is affixed to devices filled with natural refrigerant.

This symbol warns against the flammability of natural refrigerant.

1.19 Structure of warnings


Dangerous

- A warning of "dangerous" indicates an **immediately dangerous** situation.
- If this warning is not observed, then **death** or **severe, irreversible injury** could occur.

| | |
|---|---|
|  DANGER! Type and source | |
| | Consequences of not following instructions |
| | <ul style="list-style-type: none"> ● Measure 1 ● Measure... |


Warning

- A warning of "warning" indicates a **possibly dangerous** situation.
- If this warning is not observed, then **death** or **severe, irreversible injury** could occur.

| | |
|--|---|
|  WARNING! Type and source | |
| | Consequences of not following instructions |
| | <ul style="list-style-type: none"> ● Measure 1 ● Measure... |


Caution

- A warning of "caution" indicates a **possibly dangerous** situation.
- If this warning is not observed, then **minor, reversible injury** could occur.


| | |
|--|---|
|  CAUTION! Type and source | |
| | Consequences of not following instructions |
| | <ul style="list-style-type: none"> ● Measure 1 ● Measure... |

Notice

A "notice" warns that dangers to property or the environment may exist.

| | |
|---|--|
|  | NOTICE! Type and source |
| | Consequences of not following instructions |
| | <ul style="list-style-type: none">● Measure 1● Measure... |


2 Unpacking


DANGER!
 Transport damage

Electric shock

- Closely inspect the device for transport damage prior to commissioning!
- Never operate a device that has sustained transport damage!

The following safety notice is relevant for bath thermostats:



NOTICE!
 Danger of device falling or overturning

Device damage

- Never lift the device by the component bridge.

The following instruction is relevant for heat thermostats:

- Hold on under the heat thermostats to lift and carry them.
1. Unpack the device.


Keep the original packaging of your constant temperature equipment for subsequent transportation.

2. Check the device and accessories for completeness and transport damage immediately after delivery.



If the device or accessories are damaged contrary to expectations, immediately inform the shipping company so that a damage report can be compiled and the transport damage inspected. Also notify LAUDA Service Temperature control devices immediately. You will find the contact information here ↪ Chapter 13.4 “Contact LAUDA” on page 124.

Table 2: Standard accessories for all devices

| Device type | Designation | Quantity | Cat. No. |
|------------------------------------|--|----------|----------|
| All devices | Operating manual | 1 | YACD0103 |
| All devices | Base remote control unit | 1 | LRT 922 |
| Devices with refrigerating machine | Hose nozzle 10 mm outer diameter with screw cap G3/8” internal | 2 | EOA 078 |

Table 3: Standard accessories for cooling bath thermostats

| Device type | Designation | Quantity | Cat. No. |
|---------------------------|-------------|----------|----------|
| RP 1090, RP 10100 | Bath cover | 1 | HDQ 154 |
| RP 2040, RP 2045, RP 2090 | Bath cover | 1 | HDQ 157 |
| RP 3035 | Bath cover | 1 | HDQ 156 |

Table 4: Standard accessories for thermal bath thermostats

| Device type | Designation | Quantity | Cat. No. |
|-------------|-------------|----------|----------|
| P 10 | Bath cover | 1 | HDQ 154 |
| P 20 | Bath cover | 1 | HDQ 157 |
| P 30 | Bath cover | 1 | HDQ 156 |

3 Structure and function

3.1 Structure

3.1.1 Structure of the bath thermostat

Front view



Fig. 1: Heating bath thermostat, front view

- 1 Base remote control unit
- 2 Visual operation and fault indicator (LED)
- 3 Bath cover
- 4 Component bridge
- 5 Mains switch
- 6 Socket 70S for connecting the operating unit
- 7 Draining nozzle (for connecting a hose)
- 8 4 feet

Back



Fig. 2: Heating bath thermostat, rear view

- 1 Type plate
- 2 Power supply
- 3 Interface panel (obscured)
- 4 Rotary knob for maximum temperature T_{\max} and release button (obscured)
- 5 Bath cooling connection sockets (refrigerant inlet IN; refrigerant outlet OUT)

3.1.2 Structure of the circulation thermostats

Front



Fig. 3: Circulating thermostat with refrigerating machine, front view

- 1 Mains switch (on side)
- 2 Recessed grip
- 3 Front panel (detachable)
- 4 Feet at front; castors at rear
- 5 Ventilation grid
- 6 Interfaces
- 7 Base remote control unit
- 8 Tank filler neck
- 9 Visual operation and fault indicator (LED)




Fig. 4: Circulation thermostat with refrigerating machine, rear view

- 1 Rotary knob for maximum temperature T_{max} and release button
- 2 Pump nozzle inflow OUT and return IN
- 3 Overflow and ventilation of expansion tank
- 4 Draining nozzle (for connecting a hose)
- 5 Connection sockets for refrigerant inlet IN and refrigerant outlet OUT
- 6 Type plate
- 7 Handle
- 8 Power supply

Front of RP 290 E



Fig. 5: Circulation thermostat with refrigerating machine, front view

- 1 Mains switch (on side)
- 2 Recessed grip
- 3 Front panel (detachable)
- 4 Feet at front; castors at rear
- 5 Ventilation grid
- 6 Interfaces
- 7 Base remote control unit
- 8 Tank filler neck
- 9 Visual operation and fault indicator (LED)



Fig. 6: Mains switch



Fig. 7: Nitrogen connection RP 290 E

3.2 Operating elements

3.2.1 Mains and safety switch



Fig. 8: Mains switch

The mains switch can be set to the following positions:

- Position [I] switches the device on.
- Position [O] switches the device off.

The mains switch also functions as a safety switch.

1. If a fault current occurs, the fuse triggers and the mains switch moves to position [O].
 - ▶ The device is switched off.
2. Pull the mains plug from the power socket.
3. Rectify the mains fault.
4. Plug the mains cable into the power socket and set the mains switch to position [I].
 - ▶ The device starts.



If the safety switch jumps back to the [O] position, contact LAUDA Service Temperature control devices.

3.2.2 Release button and maximum temperature knob



Fig. 9: Release button and Tmax knob

Set the maximum temperature T_{max}
Release button

- Rotary knob with scale for setting the maximum permitted temperature [Tmax], adjusted using a screwdriver. Refer to Chapter 5.8 “Setting overtemperature protection Tmax” on page 69 for more information on setting the temperature.
- In the event of a malfunction, press the [Release] button once the fault is rectified.

3.3 Functional elements

3.3.1 Hydraulic circuit

The hydraulic circuit refers to the circuit that the heat transfer liquid flows through.

The circuit essentially consists of the following components:

- Bath containing heat transfer liquid
- Heater for heating the heat transfer liquid
- Refrigerating machine for cooling the heat transfer liquid

Pump in the bath thermostat

The bath thermostat is fitted with a variopump (pressure pump) for internal bath circulation. The pump can be set to one of 8 pump levels (may be fewer depending on the device) to optimize bath circulation, noise emissions and mechanical heat input.

The automatic SteadyFlow function for the pump motor allows you to circulate high-viscosity heat transfer liquids at the same flow rate as low-viscosity heat transfer liquids.

The variopump can operate briefly at a maximum viscosity of 150 mm²/s. However, 50 mm²/s should not be exceeded during regular operation. The ideal temperature controller setting is 30 mm²/s or lower.

Pump in the circulating thermostat

The circulating thermostat is fitted with a powerful vario flex pump (pressure-suction pump) for controlling the temperature of the consuming unit effectively. The pump can be set to one of 8 pump levels (may be fewer depending on the device) to optimize the output, conveyance pressure, noise emissions and mechanical heat input.

The automatic SteadyFlow function for the pump motor allows you to circulate high-viscosity heat transfer liquids at the same flow rate as low-viscosity heat transfer liquids.


The vario flex pump can operate briefly at a maximum viscosity of 150 mm²/s. However, 50 mm²/s should not be exceeded during regular operation. The ideal temperature controller setting is 30 mm²/s or lower.

Cooling coil in the bath

All thermal bath thermostats and thermal circulating thermostats are fitted with a cooling coil for internal bath cooling as standard.


- A cooling source such as a fresh water supply can be connected to the cooling coil connection sockets.
- See ↗ Table 20 “Cooling water data” on page 117 for information on inner hose diameters.
- The bath temperature of the thermostat can be decreased to approximately 5 °C above the temperature of the cooling water (without an external consuming unit).
- The LCZ 9771 cooling water valve (with LiBus triggering) available as an accessory only opens the cooling water supply when cooling is required.

Operating the cooling coil in a central cooling water system

| | |
|---|--|
|  | CAUTION! Operation with cooling coil, discharge of hot steam/boiling cooling water |
| | Scalding |
| | <ul style="list-style-type: none"> ● Only use the cooling coil up to a bath temperature of 95 °C. |

The cooling coil is approved for PRO heating thermostats (bath thermostats and circulation thermostats) operated on a central cooling water system up to a bath temperature of 95 °C. In practice, the operating pressures in a central cooling water system vary significantly and the return pipes are not depressurized, which means that the cooling coil does not drain completely when the cooling fluid supply is closed. If temperatures are higher than the boiling point of the cooling water, the high degree of heat lost when the cooling water evaporates in the cooling coil impairs the temperature process enormously. Furthermore, the effect of possible bursts of steam on the central cooling water circuit or connected consuming units should not be underestimated.

Operating the cooling coil with drinking water

| | |
|---|--|
|  | WARNING! Operation with cooling coil, hot steam bursts/hot steam at bath temperatures above 95 °C |
| | Scalding |
| | <ul style="list-style-type: none"> ● The open end of the cooling coil hose must be secured to the outlet. |

The cooling coil is approved for PRO heating thermostats (bath thermostats and circulation thermostats) operated on a drinking water pipeline with depressurized outlet up to a bath temperature of 155 °C. It is possible to operate the cooling water valve safely with water on a PRO heating thermostat above 100 °C because the cooling water can drain from the cooling coil on the heating thermostat and does not have to evaporate completely first. If the cooling fluid supply opens and cooling water enters the cooling coil at a bath temperature of more than 95 °C, it produces a brief burst of steam, which is why the open end of the cooling coil hose must be secured to the outlet. The hoses leading to and from the cooling coil must slope downwards all the way to the outlet.

The cooling capacity of the bath cooling coil depends on the bath temperature of the thermostat and the temperature of the cooling water. If oil is used as heat transfer liquid instead of water under similar temperature conditions, a slightly lower cooling capacity can be expected. If higher bath temperatures (up to 155 °C) are reached during operation, the cooling capacity increases because of the high thermal gradients between the heat transfer liquid and cooling water.

3.3.2 Refrigerating machine

The refrigerating machine consists of the following main components:

- Compressor
A piston compressor is used in the refrigerating machine. The compressor is protected by a motor protection switch, which reacts to the temperature and current consumption of the compressor. The compressor switches on automatically but can also be activated manually via the control menu. If safety-related faults occur, the refrigerating machine is switched off automatically.
- Evaporator
A stainless steel tube coil evaporator extracts heat from the internal bath.
- Electronic expansion
Modern electronic expansion valves expand the refrigerant. Cooling requirements can be controlled with extreme precision using a procedure developed and patented by LAUDA.
- SmartCool system
A special form of proportional cooling combined with a controlled fan. With proportional cooling, the required cooling capacity is set virtually proportional to the controller signal. Proportional cooling can save up to 75 % energy compared to standard cooling methods that cool and reheat. The automatic cooling unit also switches the refrigerating machine off completely if cooling is not required for a prolonged period.
- SelfCheck assistant
All parameters and modes for switching off the heating control and sensors are checked before actual operation starts. The system not only displays alarm messages and fault messages, but also notifies the operator of the need to perform maintenance, such as cleaning the air-cooled condenser.



The refrigerating machines may contain natural refrigerant, depending on the model. These refrigerants are combustible.



The refrigerating machines may contain fluorinated refrigerant, depending on the model.

Refer to ↗ Chapter 11.2 “Refrigerating machine and cooling water” on page 116 for technical specifications relating to the different cooling thermostats.

3.3.3 Heat discharge through cooling in a hybrid design

Hybrid cooling

The heat of the refrigerating machine is discharged by a combined air and water cooling system. The user can cool using either air or water at any time. If the user opens the cooling water supply to the device while the device is operating, the system switches automatically from air cooling to water cooling. If the cooling water system does not discharge enough heat energy, the device switches on air cooling automatically as a supporting measure.

- In air-cooled mode, the device is cooled with air, whereby the fan draws in fresh air through the front of the device. The fresh air heats up inside the device and is discharged at the sides and back of the device.
- In water-cooled mode, the heat is discharged via the cooling water circuit. On the standard version of the device, the cooling water volume is unregulated, but can be controlled by adding the accessory "cooling water valve" (on/off).
- The fan on the air-cooled condenser must also operate at a low speed for the compressor to cool.



The cooling water must be a minimum of 5 – 10 K cooler than the ambient temperature of the device to ensure efficient cooling.


3.3.4 Nitrogen overlay

This section is relevant for device RP 290 E.

The nitrogen overlay ...

- is guided directly over the surface of the heat transfer liquid in the circulation thermostats. The nitrogen flows out through the device overflow.
- reduces the condensation of moisture in the heat transfer liquid.
- reduces oxidation of the heat transfer liquid.
- increases the service life of the heat transfer liquid.
- decreases the flammability of combustible heat transfer liquids.

Please note:

- An overflow hose with collecting vessel must be connected to the overflow of the circulation thermostat, see  Chapter 4.8.2 "Connecting an external consuming unit" on page 53.
An excessive nitrogen flow rate may cause heat transfer liquid to be drawn through the circulation thermostat overflow.
- The nitrogen overlay must not be used in closed rooms. The operating areas must be well ventilated. Alternatively, use an extraction system.
- Ignition sources must be avoided at the filling opening and overflow if heat transfer liquids are operated near their flash point temperature.

Connection



Fig. 10: Nitrogen connection (N₂)

Push-in connection on the rear of the device that can be operated without tools, compatible with 6 mm pneumatic hoses (Teflon, PE), LAUDA Article No. RKJ 048. The push-in connection is automatically closed when the hose is not inserted.

Installation: Simply insert the hose into the connection.

Removal: Push the blue ring and then simply pull out the hose.

Adjusting the flow rate

A gas dosing device is required to adjust the nitrogen flow rate. The dosing device is not included in the delivery. A pressure reducer with outflow tap can be used as a dosing device, for example.

- A nitrogen flow rate of 0.5 – 5 liters per hour is recommended.

3.3.5 Series standard and optional interfaces

The following sections contain a general overview of all standard interfaces on the device as well as additional interface modules.



Equipment connected to the low-voltage inputs and outputs must be safely insulated against dangerous contact voltages as per DIN EN 61140, for example, using double or reinforced insulation as per DIN EN 60730-1 or DIN 60950-1.



Refer to the separate operating manual accompanying the interface modules for further information on installing and operating these interface modules. Each respective operating manual must be observed in order to use the module as intended.

Standard interfaces



Fig. 11: Interface panel

Additional interfaces


- The Base or Command Touch remote controls are connected via the **LiBus interface** (marked with designation 70S LiBus).
- The **USB device interface** (type B) allows connection to a PC. Software updates are transferred to the device via this USB interface (for updaters only, not a process interface).
- The **Ethernet interface** offers the customer the opportunity to control and monitor the temperature processes carried out by LAUDA thermostatic circulator through a LAUDA interface command set (process interface).
- The external Pt100 temperature probe is connected to the **Pt100 interface** (marked with designation 10S Pt100).

Additional interface modules can be installed in the devices.

- The **Analog module** (order no. LRZ 912) has a 6-pin DIN socket with two inputs and two outputs. The inputs and outputs can be configured as a 0 – 20 mA, 4 – 20 mA or 0 – 10 V interface independently of one another. A voltage of 20 V applied to the socket supplies power to an external sensor with electronic evaluation unit.
- The **RS 232/485 interface module** (order no. LRZ 913) is available in a 9-pin SUB-D socket design and is galvanically isolated by an optocoupler. When combined with the LAUDA command set, the module is compatible with the ECO, Variocool, Proline, Proline Kryomat, PRO, Integral XT and Integral T product lines. The RS232 interface can be connected directly to the PC using a 1:1 contacted cable.
- The **contact module** (order no. LRZ 914) is available in a plug connector design according to NAMUR NE28. This contact module is identical to LRZ 915, but only has two DIN sockets, each with one output and one input. The coupling socket (order no. EQD 047) and the coupling connector (order no. EQS 048) have a 3-pin design.
- The **contact module** (order no. LRZ 915) is available in a 15-pin SUB-D socket design. The module has three relay contact outputs (changeover contacts, maximum 30 V/ 0.2 A) and three binary inputs for control via external floating contacts.
- **Profibus module** (order no. LRZ 917). Profibus is a bus system used primarily in the chemical industry, which can connect a maximum of 256 devices at a high signal transmission rate.
- **EtherCAT module** (order no. LRZ 922) with M8 connection sockets.
EtherCAT module (order no. LRZ 923) with RJ45 connection sockets. EtherCAT is an Ethernet-based fieldbus with master/slave functionality.
- **External LiBus module box** (order no. LCZ 9727) with two additional module bays. The number of LiBus interfaces can be increased using the LiBus module box (LCZ 9727). Additional modules such as a solenoid valve for regulating the cooling water or a return protection can subsequently be connected.

Refer to the operating manual accompanying the relevant LAUDA interface module for further information on connecting and using these interfaces.

3.3.6 Type plate

| LAUDA Made in Germany | |
|--|-----------------|
| Type: | RP 3035 |
| Catalog No. / Bestell Nr. | L000009 |
| Serial No. / Serien Nr. | L000009-16-0001 |
| Refrigerant / Kältemittel I | R-290 |
| Filling charge / Füllmenge I | 110 g |
| PS high pressure / Hochdruck I: | 24 bar |
| PS low pressure / Niederdruck I: | 14 bar |
| Refrigerant / Kältemittel II | R-170 |
| Filling charge / Füllmenge II | 80 g |
| PS high pressure / Hochdruck II: | 24 bar |
| PS low pressure / Niederdruck II: | 14 bar |
| Voltage / Spannung: | 230 V; 50 Hz |
| Power consumption / Leistungsaufnahme | 3,68 kW |
| Protection class / Schutzart | IP 21 |
| Fuse / Sicherung  | |
| Klasse nach DIN 12876-1 | III / FL |



| | |
|---|---|
|  |  |
| LAUDA DR. R. WOBSEY GMBH & CO. KG 97922 Lauda-Königshofen, Pfarstr. 41/43, Germany | |

Fig. 12: Type plate

The specifications on the type plate are described in more detail in the following table. Certain specifications depend on the device type and the device options installed. Installed options are marked with a corresponding addendum.

| Specification | Description |
|--------------------------------|--|
| Type | Device type |
| Article-No. | Order number of the device |
| Serial no. | Serial number of the device |
| Refrigerant I | Designation of the refrigerant used in the refrigerating machine, level 1 |
| Filling charge I | Filling charge of the refrigerant in the refrigerating machine, level 1 |
| PS high pressure I | Maximum permitted operating pressure at the refrigerant high-pressure side in the refrigerating machine, level 1 |
| PS low pressure I | Maximum permitted operating pressure at the refrigerant low-pressure side in the refrigerating machine, level 1 |
| Refrigerant II | Designation of the refrigerant used in the refrigerating machine, level 2 |
| Filling charge II | Filling charge of the refrigerant in the refrigerating machine, level 2 |
| PS high pressure II | Maximum permitted operating pressure at the refrigerant high-pressure side in the refrigerating machine, level 2 |
| PS low pressure II | Maximum permitted operating pressure at the refrigerant low-pressure side in the refrigerating machine, level 2 |
| Voltage | Device may only be operated with this supply voltage and frequency |
| Power consumption | Maximum power consumption of the device during operation |
| Protection level | IP protection level of the device |
| Fuse | Device fitted with automatic fuse |
| Class according to DIN 12876-1 | German standard for electrical laboratory equipment |

4 Before starting up

4.1 Installation



WARNING!
Danger of device falling or overturning

Crushing, impacts

- Do not tilt the device.
- Position the device on an even, non-slip surface with a sufficient load carrying capacity.
- Do not position the device close to table edges.

The following instruction is relevant for heat thermostats:

- Hold on under the heat thermostats to lift and carry them.

The following safety notice is relevant for devices with a refrigerating machine:



WARNING!
Danger of overpressure from high ambient temperature

Injury, escape of refrigerant

- Note the permitted ambient temperature.

The following safety notices are relevant for devices containing natural refrigerant:



WARNING!
Explosive gas mixture resulting from leakage in refrigerant circuit

Fire, explosion

- Devices containing less than 150 g of combustible refrigerant are not subject to special installation conditions. However, a minimum volumetric flow of 1 m³ for every 8 g of refrigerant is recommended.



WARNING!
Collection of refrigerant in an installation space similar to a trough

Fire, explosion

- Installation of the device in a space similar to a trough is not permitted.

The following safety notice is relevant for bath thermostats:



NOTICE! Danger of device falling or overturning

Device damage

- Never lift the device by the component bridge.

Please note:

- Irritant vapors may develop, depending on the heat transfer liquid and operating mode used. Always ensure that the vapors are adequately extracted. Use the bath cover for bath thermostats.
- Note the electromagnetic compatibility (EMC) requirements of the device. Refer to [↗ Chapter 1.2 “EMC requirements”](#) on page 7 for more information.

Observe the information relating to devices with a refrigerating machine:

- The device can be operated at a maximum ambient temperature of 40 °C.
- A higher ambient temperature may have a negative impact on the cooling output of the thermostats used.
- After a prolonged period of inactivity, it may take the cooling thermostat up to 30 minutes to reach the nominal cooling output, depending on the room temperature and device type.
- After transporting the refrigeration device, install 2 hours before commissioning if possible so that any displaced oil can flow back into the oil sump and the compressor is not damaged.



The type and refrigerant charge are printed on the type plate.

1. Position the device on a table in a suitable space.
2. Keep the device away from other objects and the wall [↗ Chapter 11.1 “General data”](#) on page 113.

Do not cover the ventilation openings.

4.2 Installing interface modules

The device can be upgraded with an optional interface module, which is inserted into the side of the device (dimensions of module bay opening 51 mm x 27 mm).

Additional modules can be inserted into the LiBus module box (LCZ 9727). The LiBus module box incorporates two module bays and is available as an accessory.



Refer to [↗ Chapter 3.3.5 “Series standard and optional interfaces”](#) on page 27 for more information on interface modules.



WARNING!
Touching pieces charged with voltage when installing the modules

Electric shock

- Disconnect the device before installing modules.

Description for installing an interface module

1. Touch the grounded bare stainless steel panels on the constant temperature equipment in order to discharge any possible electrostatic charge.
2. Turn off the constant temperature equipment and pull out the mains plug.
3. Remove the module from its packaging.
4. The module bays are protected with a cover. Carefully remove the cover.
5. Carefully remove the bus connection cable from the cover.
6. Insert the bus connection cable (red plug with red socket).



The plug and the socket are reverse polarity protected.

7. Insert the module into the bay and fasten it with the two cross-head screws.
 - ▶ The interface module is ready for use.

4.3 RS 232 interface

4.3.1 Cable and test of the RS 232 interface

| Signal | Computer | | | | Thermostat | | Signal |
|---------------|-------------------------|----------------------------|-------------------------|----------------------------|-------------------------|----------------------------|---------------|
| | 9-pin sub-D socket | | 25-pin sub-D socket | | 9-pin sub-D socket | | |
| | With hardware handshake | Without hardware handshake | With hardware handshake | Without hardware handshake | With hardware handshake | Without hardware handshake | |
| RxD | 2 | 2 | 3 | 3 | 2 | 2 | TxD |
| TxD | 3 | 3 | 2 | 2 | 3 | 3 | RxD |
| DTR | 4 | | 20 | | 4 | | DSR |
| Signal ground | 5 | 5 | 7 | 7 | 5 | 5 | Signal ground |
| DSR | 6 | | 6 | | 6 | | DTR |
| RTS | 7 | | 4 | | 7 | | CTS |
| CTS | 8 | | 5 | | 8 | | RTS |

With hardware handshake: When connecting a thermostat to the PC, use a 1:1 cable (not a null modem cable). The RS 232 interface can be connected directly to the PC using a 1:1 contacted cable.

Without hardware handshake: Set the corresponding operation mode on the PC.

Note the following instructions:

- Use protected connection lines.
- Connect the protective screen with the connector shell.
- The lines are galvanically separated from the rest of the electronics.
- Do not connect unassigned pins.

It is easy to check the RS 232 interface when it is connected to a PC with a Microsoft Windows operating system.

- For Windows® 3.11 with the program "Terminal".
- For Windows® 95/98/NT/XP with the program "HyperTerminal".

For the operating systems Windows Vista, Windows 7, and Windows 8, "HyperTerminal" is no longer part of the operating system.

- Terminal programs are available for download from the Internet for free. These programs offer features similar to "HyperTerminal" (for example PuTTY or RealTerm). Search query "serial port terminal program".

4.3.2 Protocol RS 232

Note the following instructions:

- Connection to SUB-D socket 9-pin
- The interface works with 1 stop bit, without a parity bit and with 8 data bits.
- Transmission speed alternately: 2400, 4800, 9600 (factory setting) or 19200 bauds.
- The RS 232 interface can be operated with AND without hardware handshake (RTS/CTS). In order to do so, Pin 4 (DSR) and Pin 6 (DTR) and Pin 7 (CTS) and Pin 8 (RTS) must be connected with a bridge.
- The command from the computer must be made with a CR, CRLF, or LFCR.
- The response from the thermostat is always made with a CRLF.
- After each command sent to the thermostat, it is necessary to wait for the reply before sending another command. This ensures that the sequencing of inquiries and answers is clear.
CR = Carriage Return (Hex: 0D); LF = Line Feed (Hex: 0A)

Table 5: Example for set value transfer from 30.5 °C to the thermostat.

| Computer | Thermostat |
|----------------------|------------|
| "OUT_SP_00_30.5"CRLF | ⇔ |
| ⇔ | "OK"CRLF |

4.3.3 Connecting cable RS 485

Connection RS 485

| Thermostat with 9-pin sub-D socket | |
|------------------------------------|-----------------------------|
| Contact | Data |
| 1 | Data A (-) |
| 5 | SG (Signal Ground) optional |
| 6 | Data B (+) |

Note the following instructions:

- Use protected connection lines.
- Connect the protective screen with the connector shell.
- The lines are galvanically separated from the rest of the electronics.
- Do not connect unassigned pins.

Termination



Fig. 13: RS 485 termination

An RS 485 bus **always** requires a bus connection in the form of a termination network that guarantees a defined standby state in the high-ohm phases of bus operation. The bus connection looks like this:

This termination network is usually integrated in the insertable PC card (RS 485) and activated via jumpers.

4.3.4 Protocol RS 485

Note the following instructions:

- The interface works with 1 stop bit, without a parity bit and with 8 data bits.
- Transmission speed alternately: 2400, 4800, 9600 (factory setting) or 19200 baud.
- The device address always precedes the RS 485 commands. Up to 127 addresses are possible. The address must always consist of three digits (A000... to A127...).
- The command from the computer must be made with a CR.
- The response from the thermostatic circulator is always made with a CR.

CR = Carriage Return (Hex: 0D)

Example with set point transfer of 30.5 °C to the thermostatic circulator. In this example, the address 15 is used.

| Computer | Thermostatic circulator |
|--------------------------|-------------------------|
| "A015_OUT_SP_00_30.5" CR | ➔ |
| ➔ | "A015_OK" CR |

4.4 Ethernet interface

4.4.1 Connections via the Ethernet interface

Various methods can be used to connect a LAUDA thermostatic circulator to a control station or PC. The control station/PC can be used to monitor and control the thermostatic circulator.

Connected via Ethernet cable



Fig. 14: Connected via Ethernet cable

Fig. 14 illustrates direct communication between the LAUDA thermostatic circulator and the control station/PC via an Internet cable.

Advantage of this connection:

- A network is not required.

Connected via LAN




Fig. 15: Connected via LAN

Fig. 15 illustrates how the thermostatic circulator is connected to a control station/PC via a LAN network.

Advantages of this connection:

- The thermostatic circulator can be controlled by any control station/PC.
- It cannot be controlled simultaneously by two control stations/PCs.

Connected via LAN and WLAN



Fig. 16: Connected via LAN and WLAN

Fig. 16 illustrates the connection between the LAUDA thermostatic circulator and a LAN network with control station/PC via a WLAN. Here, the thermostatic circulator is connected to a WLAN router using a standard Ethernet cable. The WLAN router must be configured so that it establishes a connection to a LAN via another WLAN router. This kind of connection is called a WLAN bridge. Refer to the instructions accompanying the relevant router for information on configuring WLAN routers.

It cannot be controlled simultaneously by two control stations.

Advantages of this connection:

- The thermostatic circulator can be controlled by any control station/PC.
- The thermostatic circulator can be contacted by radio and operated from a remote location.

Connected via WLAN



Fig. 17: Connected via WLAN

Fig. 17 illustrates direct communication between the control station/PC and the LAUDA thermostatic circulator via a WLAN. The WLAN router must be configured as an access point. Refer to the instructions accompanying the router for information on configuring the WLAN router.

Advantages of this connection:

- The thermostatic circulator can be contacted by radio and operated from a remote location.
- It is possible to use a short Ethernet cable.
- No LAN network required.

Notes


- Commercially available WLAN routers can be used for the connections displayed in Fig. 16 and Fig. 17. The routers must have the necessary connection function and meet the requirements in the relevant country in which they are operated. However LAUDA recommends using an industrial WLAN router for the configuration illustrated in Fig. 16.

4.4.2 Configuring the Ethernet interface

Technical data of the Ethernet interface

| Data | Value | Unit |
|---------------------|--------|------|
| Ethernet - standard | 10/100 | MBit |

A glossary with all the relevant explanations appears at the end of the document.



PC control

- The *PC control* menu item enables the control for a PC or control station. You can activate this function if you wish to control and monitor the thermostat from a control station.

Before the constant temperature equipment and control station can be operated together in a local network (LAN), the Ethernet interface must be configured.

The Ethernet interface can be configured in two different ways:

Automatically obtain LAN settings - In order for this to work, a DHCP server must be present in the local network (LAN). If communication is direct, the control station must support the auto IP standard.

Manually configure LAN settings - Manual configuration must be performed if a DHCP server is not available, auto IP standard is not supported or you wish to use the Ethernet interface with fixed IP addresses.

Manually configure LAN settings

1. Switch on the constant temperature equipment.
2. Press any button on the Base unit to display the Home window.
3. Press the [input button] to open the menu.
4. Select the menu items from *Settings* → *Basic settings* → *Ethernet* → *LAN settings* → *DHCP client* using the cursor keys and press [OK] to confirm.
 - ▶ The options [Off] and [On] appear on the display.
5. Select the option [Off] and press [OK] to confirm.
 - ▶ The *Local IP address* window opens. The cursor marks the input field.
6. Press [OK] to confirm the input field.
 - ▶ The *Local IP address* input window opens.
7. Enter the numerical values, for example 120.0.0.13. The numerical values are entered byte by byte. From left to right, from byte 4 to byte 1. Press [OK] to confirm each byte.
8. Once you have entered the numerical values, press the [Apply] softkey.
 - ▶ The [Local mask] input window opens.
9. Enter the numerical values. The numerical values are entered byte by byte. From left to right, from byte 4 to byte 1. Press [OK] to confirm each byte.

10. Once you have entered the numerical values, press the [Apply] softkey.
 - ▶ The [DHCP client] window opens.
11. Scroll to the numerical values of the [Gateway] menu item and press [OK] to confirm.
12. Enter the numerical values. The numerical values are entered byte by byte. From left to right, from byte 4 to byte 1. Press [OK] to confirm each byte.



If you do not know the numerical values, ask someone in your IT department for the relevant values. If the wrong numerical values are entered, [Local mask] cannot be completed.

13. Once you have entered the numerical values, press the [Apply] softkey.
 - ▶ The numerical values entered in [Local IP address], [Local mask] and [Gateway] are displayed.
14. Press the left cursor button to the move up one menu level in the PC control menu item and press [OK] to confirm.
 - ▶ The options [No] and [Yes] appear on the display.
15. Select the option [Yes] and press [OK] to confirm.
 - ▶ The PC can now be controlled from the control station.
16. Switch off the constant temperature equipment.
17. Connect the Ethernet interface on the constant temperature equipment as illustrated in Fig. 15 to Fig. 17. Use a commercially available Ethernet cable (patch cable).
18. Switch on the constant temperature equipment.
19. Test the connection with ↵ “Checking the LAN network” on page 39 or ↵ “Check the LAN network and the process interface” on page 40.



Set the [DHCP client] from [On] to [Off], all numerical values are reset to 0. 0. 0. 0.



*Use the same procedure (enter LAN settings manually) if there is a **switch** between the constant temperature equipment and PC.*



When configuring direct Ethernet communication between the control station and the constant temperature equipment, it may take 1 or 2 minutes to establish the connection.

Automatically obtain LAN settings

1. Switch on the constant temperature equipment.
2. Press any button on the Base unit to display the Home window.
3. Press the [input button] to open the menu.

4. Select the menu items from *Settings* → *Basic settings* → *Ethernet* → *LAN settings* → *DHCP client* using the cursor keys and press [OK] to confirm.
 - ▶ The options [Off] and [On] appear on the display.
5. Select the option [On] and press [OK] to confirm.
 - ▶ The DHCP client is active. The Ethernet interface is configured automatically.
6. Select the entry [Yes] in the [PC control] menu.
 - ▶ The PC can now be controlled from the control station.
7. Switch off the constant temperature equipment.
8. Connect the Ethernet interface on the constant temperature equipment as illustrated in Fig. 15 to Fig. 17. Use a commercially available Ethernet cable (patch cable).
9. Switch on the constant temperature equipment.
10. Test the connection with ↵ “Checking the LAN network” on page 39 or ↵ “Check the LAN network and the process interface” on page 40.

Checking the LAN network

1. Start the Windows command processor by entering `cmd.exe` ↵ on the PC with Microsoft Windows operating system.
 - ▶ The entry window will open.
2. There are two ways of checking:
 - Enter the ping command together with the IP address.
`ping xxx.xxx.xxx.xxx` ↵
 For "xxx.xxx.xxx.xxx", put the IP address that was entered when the Ethernet interface was configured.
 Or
 - Enter the ping command together with the serial number of the thermostatic circulator (possible with software control system 1.36 or later).
`ping serial number` ↵
 - ▶ If the Ethernet interface is configured and connected correctly, the interface will return four responses within a very short time. See Fig. 18.

```
Administrator: C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. Alle Rechte vorbehalten.

C:\Users\Knoll>ping 172.17.20.22

Ping wird ausgeführt für 172.17.20.22 mit 32 Bytes Daten:
Antwort von 172.17.20.22: Bytes=32 Zeit<1ms TTL=64
Antwort von 172.17.20.22: Bytes=32 Zeit<1ms TTL=64
Antwort von 172.17.20.22: Bytes=32 Zeit<1ms TTL=64
Antwort von 172.17.20.22: Bytes=32 Zeit<1ms TTL=64

Ping-Statistik für 172.17.20.22:
    Pakete: Gesendet = 4, Empfangen = 4, Verloren = 0
    (0% Verlust),
    Ca. Zeitangaben in Millisek.:
    Minimum = 0ms, Maximum = 1ms, Mittelwert = 0ms

C:\Users\Knoll>
```

Fig. 18: Example for entering the ping command

Check the LAN network and the process interface

It is easy to check the connection to the interface with a PC and Microsoft Windows operating system.

- For Windows 3.11 with the program "Terminal".
- For Windows 95/98/NT/XP the program "HyperTerminal".
- For operating systems Windows Vista, Windows 7 and Windows 8 "HyperTerminal" is not part of the operating system*.



** Terminal programs are available on the Internet as freeware. These programs offer features similar to "HyperTerminal" (for example PuTTY or RealTerm). Search query "serial port terminal program".*

Checking with RealTerm

1. Open the program "HyperTerminal" or the "terminal program" on a PC with Microsoft Windows operating system.
 - ▶ The entry window will open.




Fig. 19: "RealTerm" program

2. Place a checkmark under *Half Duplex* in the *Display* tab.




Fig. 20: Entry in the Port field

3. Enter the configured IP address and port number of the Ethernet interface on the constant temperature equipment in the *Port* tab. When you are doing this, be sure that the IP address and port number are separated by a colon.
You can enter the serial number of the constant temperature equipment instead of the IP address.
4. Then press the [Open] button.
5. Open the *Send* tab.
 - ▶ Now that the program has been configured, the actual test can begin.
6. Place a checkmark under *+CR* and *+LF*.




Fig. 21: Entries for the test

7. A command must be sent to the constant temperature equipment to test communication. For example, TYPE. Enter the command and press [Send File].

See ↗ Chapter 4.5.1 “Write commands of the interface” on page 44 and ↗ Chapter 4.5.2 “Read commands of the interface” on page 46 for a list of interface commands.

- ▶ If the connection is operational, the constant temperature equipment acknowledges the command.

4.4.3 Data transfer rate

The data transfer rate cannot be precisely defined. It depends on a variety of different factors:

- Are the constant temperature equipment (with the Ethernet interface) and the control station/PC on the same network?
- Are the control station/PC and constant temperature equipment connected wirelessly (WiFi) or through a cable?
- What is the load on the network?

Generally commands can be sent to the constant temperature equipment every 500 ms. For WiFi connections the period could exceed 1 s. A new command can only be sent if the previous command has been acknowledged by the constant temperature equipment.

4.4.4 Protocol of the interface

Note the following instructions:

- The command from the computer must be made with a CR, CRLF, or LFCR.
- The response from the thermostatic circulator is always made with a CRLF.
- After each command sent to the thermostat, it is necessary to wait for the reply before sending another command. This ensures that the sequencing of inquiries and answers is clear.

CR = Carriage Return (Hex: 0D); LF = Line Feed (Hex: 0A)

Table 6: Example with set point transfer of 30.5 °C to the thermostatic circulator

| Computer | Temperature control device |
|----------------------|----------------------------|
| "OUT_SP_00_30.5"CRLF | ➔ |
| ➔ | "OK"CRLF |

4.5 Read and write errors on the interfaces

4.5.1 Write commands of the interface

Valid for the Ethernet interface and for the RS 232/485 interface module

A write error is a command from the control station to the thermostatic circulator.

| Command | Meaning |
|------------------|--|
| OUT_PV_05_XXX.XX | Specify external temperature through the interface |
| OUT_SP_00_XXX.XX | Temperature set point with maximum 3 digits in front of the decimal point and a maximum of 2 digits after. |
| OUT_SP_01_XXX | Pump performance level 1 to 8 |
| OUT_SP_02_XXX | Mode of operation cooling (0 = OFF / 1 = ON / 2 = AUTOMATIC) |
| OUT_SP_04_XXX.X | TiH flow temperature limit upper value |
| OUT_SP_05_XXX.X | TiL flow temperature limit lower value |
| OUT_SP_07_XXX.X | Safety Mode temperature set point |
| OUT_SP_08_XX | Interface communication timeout (1 – 60 s; 0 = OFF) |
| | |
| OUT_PAR_00_XXX.X | Configuration of control parameter Xp. |
| OUT_PAR_01_XXX | Configuration of control parameter Tn (5 – 180 s; 181 = OFF). |
| OUT_PAR_02_XXX | Configuration of control parameter Tv. |
| OUT_PAR_03_XX.X | Configuration of control parameter Td. |
| OUT_PAR_04_XX.XX | Configuration of control parameter KpE. |
| OUT_PAR_05_XXXX | Configuration of control parameter TnE (0 – 9000 s; 9001 = OFF). |

| Command | Meaning |
|--------------------------------------|--|
| OUT_PAR_06_XXX | Configuration of control parameter TvE (5 = OFF). |
| OUT_PAR_07_XXXX.X | Configuration of control parameter TdE. |
| OUT_PAR_09_XXX.X | Configuration of the correction limitation. |
| OUT_PAR_10_XX.X | Configuration of control parameter XpF. |
| OUT_PAR_14_XXX.X | Configuration of the set point offset. |
| OUT_PAR_15_XXX | Configuration of control parameter PropE. |
| | |
| OUT_MODE_00_X | Keyboard for Base remote control: 0 = free / 1 = blocked (corresponds to: "KEY"). |
| OUT_MODE_01_X | Control: 0 = internal / 1 = external Pt100 / 2 = external analog / 3 = external serial. |
| OUT_MODE_03_X | Keyboard remote control unit command: 0 = free / 1 = blocked. |
| OUT_MODE_04_X | Target value offset source: 0 = normal / 1 = external Pt / 2 = external analog / 3 = external serial. |
| OUT_MODE_05_X | 1 = Activate Safety Mode / 0 = Deactivate Safety Mode |
| | |
| START | Turns device on (from standby mode) |
| STOP | Switches the device to standby mode (pump, heating, cooling unit off). |
| RMP_SELECT_X | Selection of the program (1 – 5) to which other commands must make reference. Program 5 is selected after the device is turned on. |
| RMP_START | Start programmer. |
| RMP_PAUSE | Stop programmer. |
| RMP_CONT | Restart programmer after a pause. |
| RMP_STOP | End program. |
| RMP_RESET | Delete program (all segments). |
| RMP_OUT_00_XXX.XX_XXXXX_XXX.X X_X | Sets the program encoder segment (temperature, time, tolerance, and possibly pump level). A segment is attached and assigned the appropriate values. |
| RMP_OUT_02_XXX | Number of program run throughs: 0 = infinite / 1 – 250. |

Note the following instructions:

- " " (blank space) can also be used for "_".
- Response from thermostat will be "OK" or, if there is an error, "ERR_X". RS 485 interface for example "A015_OK" or if there is an error "A015_ERR_X".
- The command from the control station must be made with a CR, CRLF or LFCR.

- The response from the thermostatic circulator is always made with a CRLF.
 - After each command is sent to the thermostatic circulator, it is necessary to wait for the reply before sending another command. This ensures that the sequencing of inquiries and answers is clear.
- CR = Carriage Return (Hex: 0D); LF = Line Feed (Hex: 0A)

Acceptable data formats

| | | | | | | | |
|----------|---------|--------|-------|---------|--------|-------|------|
| -XXXX.XX | -XXXX.X | -XXXX. | -XXXX | XXXX.XX | XXXX.X | XXXX. | XXXX |
| -XXX.XX | -XXX.X | -XXX. | -XXX | XXX.XX | XXX.X | XXX. | XXX |
| -XX.XX | -XX.X | -XX. | -XX | XX.XX | XX.X | XX. | XX |
| -X.XX | -X.X | -X. | -X | X.XX | X.X | X. | X |
| -.XX | -.X | .XX | .X | | | | |

4.5.2 Read commands of the interface

Valid for the Ethernet interface and for the RS 232/485 interface module

A read error is a query for current data sent to the thermostatic circulator by the control station.

| Command | Meaning |
|----------|--|
| IN_PV_00 | Query of bath temperature (outflow temperature). |
| IN_PV_01 | Query of the controlled temperature (internal/external, Pt/external, analog/external serial) |
| IN_PV_02 | Query inflow pump pressure in bar. |
| IN_PV_03 | Query external temperature T_E (Pt100). |
| IN_PV_04 | Query external temperature T_E (analog input). |
| IN_PV_05 | Level query. |
| IN_PV_10 | Query bath temperature in 0.001 °C. |
| IN_PV_13 | Query external temperature T_E (Pt100) in 0.001 °C. |
| | |
| IN_SP_00 | Query temperature set point. |
| IN_SP_01 | Query pump power level. |
| IN_SP_02 | Query of cooling mode (0 = OFF / 1 = ON / 2 = AUTOMATIC). |
| IN_SP_03 | Query of overtemperature switch-off point. |
| IN_SP_04 | Query of outflow temperature limit T_{iH} (upper value). |
| IN_SP_05 | Query of outflow temperature limit T_{iL} (lower value). |
| IN_SP_07 | Query of Safety Mode temperature set point. |
| IN_SP_08 | Query of interface communication timeout [s]. |

| Command | Meaning |
|------------|---|
| IN_PAR_00 | Query of control parameter Xp. |
| IN_PAR_01 | Query of control parameter Tn (181 = OFF). |
| IN_PAR_02 | Query of control parameter Tv. |
| IN_PAR_03 | Query of control parameter Td. |
| IN_PAR_04 | Query of control parameter KpE. |
| IN_PAR_05 | Query of control parameter TnE (response: XXXX; 9001 = OFF). |
| IN_PAR_06 | Query of control parameter TvE (response: XXX; 5 = OFF). |
| IN_PAR_07 | Query of control parameter TdE (response: XXXX.X). |
| IN_PAR_09 | Query of the maximum correction limitation. |
| IN_PAR_10 | Query of control parameter XpF. |
| IN_PAR_14 | Query of the set point offset. |
| IN_PAR_15 | Query of control parameter PropE. |
| IN_DI_01 | Status of contact entry 1: 0 = open / 1 = closed. |
| IN_DI_02 | Status of contact entry 2: 0 = open / 1 = closed. |
| IN_DI_03 | Status of contact entry 3: 0 = open / 1 = closed. |
| IN_DO_01 | Status of contact exit 1: 0 = contact open / 1 = contact closed. |
| IN_DO_02 | Status of contact exit 2: 0 = contact open / 1 = contact closed. |
| IN_DO_03 | Status of contact exit 3: 0 = contact open / 1 = contact closed. |
| IN_MODE_00 | Keyboard for Base remote control: 0 = free / 1 = blocked (corresponds to: "KEY"). |
| IN_MODE_01 | Control: 0 = internal / 1 = external Pt100 / 2 = external analog / 3 = external serial. |
| IN_MODE_02 | Standby: 0 = device ON / 1 = device OFF. |
| IN_MODE_03 | Keyboard remote control unit command: 0 = free / 1 = blocked. |
| IN_MODE_04 | Target value offset source: 0 = normal / 1 = external Pt / 2 = external analog / 3 = external serial. |
| IN_MODE_05 | Safety Mode status: 0 = inactive / 1 = active |
| TYPE | Query of the device type (for example, answer = "PRO"). |
| VERSION_R | Query of software version number of control system. |
| VERSION_S | Query of software version number of protection system. |
| VERSION_B | Query of software version number of Command remote control. |

| Command | Meaning |
|---------------|--|
| VERSION_T | Query of software version number of cooling system. |
| VERSION_A | Query of software version number of analog module. |
| VERSION_V | Query of software version number of RS 232/485 module. |
| VERSION_Y | Query of software version number of Ethernet module. |
| VERSION_Z | Query of software version number of EtherCAT module. |
| VERSION_D | Query of software version number of digital module. |
| VERSION_M_0 | Query of software version number of solenoid valve (cooling water). |
| VERSION_M_3 | Query software version number of solenoid valve (shut-off valve 1) |
| VERSION_M_4 | Query software version number of solenoid valve (shut-off valve 2) |
| VERSION_P_0 | Query of software version number of pump 0 |
| VERSION_P_1 | Query of software version number of pump 1 |
| VERSION_P_2 | Query of software version number of pump 2 |
| VERSION_P_3 | Query of software version number of pump 3 |
| VERSION_B_1 | Query of software version number of Base |
| VERSION_E | Query software version number of external Pt100 module |
| | |
| STATUS | Query of device status 0 = OK, 1 = fault. |
| STAT | Query of fault diagnosis response: XXXXXXXX; X = 0 no fault, X = 1 fault 1st Character = error 2nd Character = alarm 3rd Character = warning 4th Character = overtemperature 5th Character = sublevel 6th Character = higher level (alarm setting) 7th Character = external control value missing |
| | |
| RMP_IN_00_XXX | Query a program segment XXX (response for example: "030.00_00010_005.00_001.00" => set temperature = 30.00 °C, time = 10 min, tolerance = 5.00 K, pump level = 1). |
| RMP_IN_01 | Query of current segment number. |
| RMP_IN_02 | Query of number of preset program sequences. |
| RMP_IN_03 | Query of current program sequence. |
| RMP_IN_04 | Query of program used as a basis for further commands. |
| RMP_IN_05 | Query of which program is currently running (0 = none). |

| Command | Meaning |
|----------------|--|
| LOG_IN_00_XXXX | Query of a measuring point XXXX from data logger (response, for example: "020.00_021.23_030.50 => set temperature = 20.00 °C, bath temperature = 21.23 °C, external temperature = 30.5 °C). |
| LOG_IN_01 | Query of all measuring points from the data logger. Unlike with the command "LOG_IN_00", a tabulator is used as a separator instead of "_". The measuring points are separated with CR and LF. The end is signaled with CR LF CR LF. |
| LOG_IN_02 | Query of start time point of data logger (response, for example: 20_14_12_20 => day 20 at 14:12:20). |
| LOG_IN_03 | Query of recording interval of data logger (response in seconds). |

Note the following instructions:

- " " (blank space) can also be used for "_".
 - If not otherwise specified in the command, the response will always be given in fixed point format "XXX.XX" or for negative values "-XXX.XX" or "ERR_X". (RS 485 interface e.g. "A015_XXX.XX" or "A015_ERR_X").
 - The command from the control station must be made with a CR, CRLF or LFCR.
 - The response from the thermostatic circulator is always made with a CRLF.
 - After each command is sent to the thermostatic circulator, it is necessary to wait for the reply before sending another command. This ensures that the sequencing of inquiries and answers is clear.
- CR = Carriage Return (Hex: 0D); LF = Line Feed (Hex: 0A)

4.5.3 Error messages from the thermostatic circulator to the control station

Error messages are described in this list.

| Error | Description |
|--------|--|
| ERR_2 | Wrong entry (for example, buffer overflow). |
| ERR_3 | Wrong command |
| ERR_5 | Syntax error in value. |
| ERR_6 | Impermissible value |
| ERR_8 | Module or value not available. |
| ERR_30 | All segments in the programmer are occupied. |
| ERR_31 | Not possible to specify set point value, analog set point input set to ON. |
| ERR_33 | An external temperature probe is missing. |
| ERR_34 | Analog value not present. |
| ERR_35 | Automatically configured |
| ERR_36 | Not possible to specify set point value, programmer is running or has been paused. |
| ERR_37 | Impossible to start the programmer, analog set point value input is turned on. |
| ERR_38 | Not possible to activate from Safety Mode. |

4.6 Setting up the circulation thermostat



CAUTION!
Risk of heat transfer liquid escaping from incorrectly sealed pump connections

Slipping hazard, loss of heat transfer liquid

- Attach a stopper or pump link to the pump connections if there is no external consuming unit connected.

4.7 Racks, platforms, rising platforms

This section is relevant for:

- the Bath thermostat device category

Chemical samples, for example, are placed on special racks, platforms and rising platforms for temperature control purposes.



NOTICE!
Risk of bath vessel corroding due to different electrochemical potentials from metal rack and bath

Device damage

- If the stainless steel vessel makes direct contact with a rack, it may result in electrochemical oxidation. Avoid using racks that may react in this way to direct contact with the vessel. Use LAUDA stainless steel racks or commercially available racks made from temperature-resistant plastic.

4.8 External consuming unit

4.8.1 Hoses



Fig. 22: Connected hoses



CAUTION!
Risk of external hydraulic circuit bursting

Scalding, cold burns

- Use hoses with a greater compressive strength than the maximum possible pump pressure.



CAUTION!
Risk of heat transfer liquid escaping

Scalding, cold burns

- The temperature and media resistance of the hoses used for the device overflow must be suitable for the application.



CAUTION!
Risk of heat transfer liquid escaping due to the use of unsuitable hoses

Scalding, cold burns

- The temperature and media resistance of the hoses must be suitable for the application temperature range.



CAUTION!
Contact with hot or cold hoses

Hot and cold burns

- Use insulated hoses for temperatures below 0 °C and above 70 °C.

Please also note the following:

- When laying the water cooling and heat transfer liquid hoses, make sure that the hoses cannot be kinked or crushed.

Approved elastomer hoses

| Hose type | Clear Ø in mm | External diameter in mm | Temperature range of the hose in °C | Application area | Cat. No. |
|-----------------------------|---------------|-------------------------|-------------------------------------|--|----------|
| EPDM hose, un-insulated | 9 | 13 | 10 – 90 | For all LAUDA heat transfer liquids except Ultra 350, Kryo 65 and mineral oils | RKJ 111 |
| EPDM hose, un-insulated | 12 | 16 | 10 – 90 | For all LAUDA heat transfer liquids except Ultra 350, Kryo 65 and mineral oils | RKJ 112 |
| EPDM hose, insulated | 12 | 35 | -35 – 90 | For all LAUDA heat transfer liquids except Ultra 350, Kryo 65 and mineral oils | LZS 021 |
| Silicone tube, un-insulated | 11 | 15 | 10 – 100 | Water, glycol/water mixture | RKJ 059 |
| Silicone tube, insulated | 11 | 33 | -60 – 100 | Water, glycol/water mixture | LZS 007 |



Refer to Chapter 5.1 “LAUDA heat transfer liquids” on page 59 for more information on heat transfer liquids.

Approved metal hoses

The following approved metal hoses with M16 x 1 cap nuts are manufactured from stainless steel. The clear opening measures 10 mm.

| Hose type | Length in cm | Temperature range of the hose in °C | Application area | Cat. No. |
|--------------------|--------------|-------------------------------------|---|----------|
| MC 50 | 50 | 10 – 400 | With single insulation, suitable for all LAUDA heat transfer liquids | LZM 040 |
| MC 100 | 100 | 10 – 400 | With single insulation, suitable for all LAUDA heat transfer liquids | LZM 041 |
| MC 150 | 150 | 10 – 400 | With single insulation, suitable for all LAUDA heat transfer liquids | LZM 042 |
| MC 200 | 200 | 10 – 400 | With single insulation, suitable for all LAUDA heat transfer liquids | LZM 043 |
| Pump short-circuit | 18 | 10 – 400 | With single insulation, suitable for all LAUDA heat transfer liquids | LZM 044 |
| MK 50 | 50 | -90 – 150 | With foam insulation for the refrigeration sector, suitable for all LAUDA heat transfer liquids | LZM 052 |
| MK 100 | 100 | -90 – 150 | With foam insulation for the refrigeration sector, suitable for all LAUDA heat transfer liquids | LZM 053 |
| MK 150 | 150 | -90 – 150 | With foam insulation for the refrigeration sector, suitable for all LAUDA heat transfer liquids | LZM 054 |

| Hose type | Length in cm | Temperature range of the hose in °C | Application area | Cat. No. |
|--------------------|--------------|-------------------------------------|---|----------|
| MK 200 | 200 | -90 – 150 | With foam insulation for the refrigeration sector, suitable for all LAUDA heat transfer liquids | LZM 055 |
| Pump short-circuit | 18 | -90 – 150 | With foam insulation for the refrigeration sector, suitable for all LAUDA heat transfer liquids | LZM 045 |

4.8.2 Connecting an external consuming unit



DANGER!
Risk of hot heat transfer liquid overflowing

Fire

- A connecting hose with a collecting vessel must be attached to the overflow.
- The collecting vessel and connecting hose must be designed to withstand the maximum temperature of the heat transfer liquid.
- Avoid ignition sources in the vicinity of the collecting vessel.



WARNING!
Degradation of overflow or drain

Electric shock

- Overflow hose and drainage hose must each slope downward separately all the way into a collecting vessel.



CAUTION!
Risk of external hydraulic circuit bursting from overpressure

Scalding, cold burns

- When laying the hoses, make sure they cannot kink.
- Use safety valves in the hydraulic circuit.



CAUTION!
Risk of heat transfer liquid escaping during operation due to open consuming unit

Scalding, cold burns

- Always use hydraulically sealed consuming units.

**CAUTION!**

Risk of heat transfer liquid escaping from consuming unit in an elevated location

Electric shock

- If the external consuming unit is positioned above the device, heat transfer liquid may escape from the device when the pump stops. Therefore use the return protection available as an accessory in the external hydraulic circuit.

**CAUTION!**

Risk of heat transfer liquid escaping from consuming units in a higher or lower location

Electric shock

- If the external consuming unit is positioned above or below the device, heat transfer liquid may escape from the device or consuming unit when the pump stops. Therefore use the constant level device available as an accessory in the external hydraulic circuit.

**CAUTION!**

Risk of external consuming unit bursting

Scalding, cold burns


- If the external consuming unit is located in a lower position and is sensitive to pressure, also take into account the additional pressure resulting from the difference in height between the consuming unit and the device.

Please also note the following:


- Always use the largest possible diameters and shortest possible hose lengths in the external circuit.
If the hose diameter is too narrow, the insufficient flow rate will cause a drop in temperature between the device and the external consuming unit. In this case, increase the bath temperature or pump level accordingly.
- Secure the hoses using hose clips.

4.9 Cooling water

4.9.1 Cooling water requirements

| | |
|--|---|
|  NOTICE! Risk of cooling circuit leaking due to corrosion | |
| | Device damage |
| | <ul style="list-style-type: none"> Do not use corrosive cooling water. |

The following safety notice is relevant for devices containing natural refrigerant:

| | |
|---|---|
|  CAUTION! Risk of cooling circuit leaking due to corrosion | |
| | Fire, explosion |
| | <ul style="list-style-type: none"> Do not use corrosive cooling water. |

Requirements

Cooling water is subject to specific purity requirements. A suitable procedure must be employed to purify the cooling water in line with the contamination in the water and maintain the water quality. Unsuitable cooling water may cause the condenser and the entire cooling water circuit to become blocked or damaged, or start to leak. The entire cooling circuit and cooling water circuit may sustain extensive consequential damage as a result. The cooling water quality depends on the local conditions.

- Free chlorine consisting of disinfectant, for example, and water containing chloride will cause pitting corrosion in the cooling water circuit.
- Distilled, deionized and demineralized water are unsuitable due to their reactivity and will cause corrosion in the cooling water circuit.
- Sea water is unsuitable due to its corrosive properties and will cause corrosion in the cooling water circuit.
- Iron particles and water containing iron will cause corrosion in the cooling water circuit.
- Hard water is unsuitable for cooling due to the high lime content and will lead to calcification of the cooling water circuit.
- Cooling water containing suspended matter is unsuitable.
- Untreated, unpurified water such as river water or cooling tower water is unsuitable due to its microbiological content (bacteria), which can settle inside the cooling water circuit.

Suitable cooling water quality

| Data | Value | Unit |
|--|-----------|------|
| pH value | 7.5 – 9.0 | --- |
| Sulfate [SO ₄ ²⁻] | < 70 | mg/L |

| Data | Value | Unit |
|--|---------------|-------------------------|
| Hydrocarbonate [HCO_3^-] / sulfate [SO_4^{2-}] | > 1.0 | --- |
| Water hardness (alkaline earth ions) | 0.71 – 1.52 | mmol/L |
| Hydrocarbonate [HCO_3^-] | 70 – 300 | mg/L |
| Conductivity | 10 – 500 | $\mu\text{s}/\text{cm}$ |
| Chloride (Cl^-) | < 50 | mg/L |
| Sulfite (SO_3^{2-}) | < 1 | mg/L |
| Free chlorine gas (Cl_2) | < 1 | mg/L |
| Nitrate (NO_3^-) | < 100 | mg/L |
| Ammonia (NH_3) | < 2 | mg/L |
| Iron (Fe), dissolved | < 0.2 | mg/L |
| Manganese (Mn), dissolved | < 0.1 | mg/L |
| Aluminum (Al), dissolved | < 0.2 | mg/L |
| Free aggressive carbon dioxide (CO_2) | < 5 | mg/L |
| Hydrogen sulfide (H_2S) | < 0.05 | mg/L |
| Algae growth | Not permitted | --- |
| Suspended matter | Not permitted | --- |

4.9.2 Connecting the cooling water



Fig. 23: Cooling water hoses (bottom)




Fig. 24: Cooling water input and output

This section is relevant for:

- Devices with refrigerating machine
- Devices with cooling coil



Refer to ↗ Chapter 11.2 “Refrigerating machine and cooling water” on page 116 for further information about the cooling water pressure, cooling water temperature and diameter of the cooling water hoses.

Please note:

- The hoses used for the cooling water circuit must be suitable for the temperature range specified. Also observe the permitted hose diameter.
- Fix the hose nipples or coupling connectors to the hose using hose clips.
- Secure the water cooling return hose in the outlet area to prevent the hose from jerking suddenly, even when pressure surges occur.
Secure the water cooling return hose in the outlet area in such a way that hot cooling water cannot spray out.
- Avoid kinking or crushing the hoses.

- We recommend using a leakage water detector with water shut-off function to prevent leakages from causing damage in the cooling water system.
- Ensure that the cooling water fulfills the requirements.
- If the condenser leaks, there is a danger that refrigerating machine oil or combustible/non-combustible refrigerant from the device's refrigerant circuit will mix with the cooling water. Observe the legal requirements and provisions of the water supply company applicable at the operation site.

5 Commissioning

5.1 LAUDA heat transfer liquids



DANGER!
Use of unsuitable heat transfer liquid

Fire

- Select a heat transfer liquid with a temperature range suitable for the application.

Please note:

- If the heat transfer liquid reaches the lower limit of the temperature range, the temperature control properties can be expected to deteriorate as a result of the increase in viscosity. Therefore, only fully utilize this temperature range when absolutely necessary.
- Never use contaminated heat transfer liquids. Contamination in the pump chamber can cause the pump to seize and the device to shut down.
- Observe the safety datasheet for the heat transfer liquid. You can request a copy of the safety datasheets at any time, if necessary.

Table 7: Permitted heat transfer liquids

| Designation | Chemical name | Working temperature range in °C | Viscosity (kin) in mm ² /s (at 20 °C) | Viscosity (kin) in mm ² /s at temperature | Flash point in °C |
|-------------|-----------------------------------|---------------------------------|--|--|-------------------|
| Kryo 95 | Silicone oil | -95 – 60 | 1.6 | 20 at -80 °C | 64 |
| Kryo 60 | Silicone oil | -60 – 60 | 3 | 25 at -60 °C | 62 |
| Kryo 51 | Silicone oil | -50 – 120 | 5 | 34 at -50 °C | 120 |
| Kryo 40 | Aqueous alkaline solution | -40 – 60 | 2.36 | 24 at -40 °C | --- |
| Kryo 30 | Monoethylene glycol/water mixture | -30 – 90 | 4 | 50 at -25 °C | 119 |
| Kryo 20 | Silicone oil | -20 – 170 | 11 | 28 at -20 °C | 170 |
| Aqua 90 | Decalcified water | 5 – 90 | 1 | --- | --- |
| Ultra 350 | Synthetic liquid | 30 – 200 | 47 | 28 at 30 °C | approx. 200 |
| Ultra 240 | Silicone oil | 80 – 240 | 170 | 39 at 80 °C | 240 |
| Therm 250 | Silicone oil | 50 – 250 | 125 | 25 at 70 °C | 300 |
| Therm 180 | Silicone oil | 0 – 180 | 23 | 36 at 0 °C | 250 |
| Therm 160 | Polyalkylene glycol and additives | 60 – 160 | 141 | 28 at 60 °C | 260 |

Table 8: Heat transfer liquid order numbers

| Designation | Container size | | |
|-------------|----------------|---------|---------|
| | Cat. No. | | |
| | 5 L | 10 L | 20 L |
| Kryo 95 | LZB 130 | LZB 230 | LZB 330 |
| Kryo 60 | LZB 102 | LZB 202 | LZB 302 |
| Kryo 51 | LZB 121 | LZB 221 | LZB 321 |
| Kryo 40 | LZB 119 | LZB 219 | LZB 319 |
| Kryo 30 | LZB 109 | LZB 209 | LZB 309 |
| Kryo 20 | LZB 116 | LZB 216 | LZB 316 |
| Aqua 90 | LZB 120 | LZB 220 | LZB 320 |
| Ultra 350 | LZB 107 | LZB 207 | LZB 307 |
| Ultra 240 | LZB 108 | LZB 208 | LZB 308 |
| Therm 250 | LZB 122 | LZB 222 | LZB 322 |
| Therm 180 | LZB 114 | LZB 214 | LZB 314 |
| Therm 160 | LZB 106 | LZB 206 | LZB 306 |

- When using Kryo 30:
The water content decreases during longer periods of operation at higher temperatures and the mixture becomes combustible (flash point 119°C). Check the mixing ratio using a hydrometer.
- When using Aqua 90:
Evaporation losses occur at higher temperatures. In this case, use a bath cover.
- When using Ultra 350:
Do not use in combination with an EPDM hose.
- Never use silicone oil in silicone tubes.
- When using mineral oils:
Do not use in combination with an EPDM hose.

Heat transfer liquid, water

- The proportion of alkaline earth ions in the water must be between 0.71 mmol/L and 1.42 mmol/L (equivalent of 4.0 and 8.0 °dH). Harder water leaves limescale deposits in the device.
- The pH value of the water must be between 6.0 and 8.5.
- Distilled, deionized and demineralized water are unsuitable due to their reactivity. High-purity water and distillates are suitable as a heat transfer liquid after 0.1 g of soda (Na_2CO_3 , sodium carbonate) is added for every liter of water.
- Sea water is unsuitable due to its corrosive properties.
- Avoid chlorine content in the water at all costs. Do not add chlorine to the water. Cleaning agents and disinfectants, for example, contain chlorine.

- The water must be free of impurities. Water with iron content is unsuitable due to rust formation and untreated river water is unsuitable due to algae growth.
- The addition of ammonia is not permitted.

5.2 Filling the device

LAUDA is not liable for damages resulting from the use of unsuitable heat transfer liquids. Approved heat transfer liquids → Chapter 5.1 “LAUDA heat transfer liquids” on page 59.



DANGER!
Risk of hot heat transfer liquid overflowing

Fire

- A connecting hose with a collecting vessel must be attached to the overflow.
- The collecting vessel and connecting hose must be designed to withstand the maximum temperature of the heat transfer liquid.
- Avoid ignition sources in the vicinity of the collecting vessel.



WARNING!
Splashing heat transfer liquid

Eye damage

- Always wear suitable safety glasses when working on the device.



WARNING!
Overflow of heat transfer liquid

Electric shock

- Do not overfill the device. Observe the level display and the thermal volume expansion of the heat transfer liquid.



WARNING!
Spraying of heat transfer liquid

Electric shock

- Avoid spraying heat transfer liquid.



WARNING!
Overflow of heat transfer liquid caused by objects placed in the bath

Scalding, cold burns

- When filling, take into account any objects placed in the bath.



WARNING!
Overflow of heat transfer liquid due to increase in volume caused by heating

Scalding, electric shock

- Take into account the increase in volume caused by heating of the heat transfer liquid.



CAUTION!
Risk of heat transfer liquid escaping

Slipping hazard

- Draining tap must be closed.



Heat transfer liquids expand when heated (approx. 10 % for every 100 °C). If an external consuming unit is connected, expansion occurs exclusively in the thermostat bath.

Bath thermostat



Fig. 25: Filling the bath thermostat

1. Close the draining tap by turning it clockwise.
2. Carefully fill the bath with heat transfer liquid.



The recommended fill level in the bath thermostat is between 30 and 100 mm below the upper edge of the bath.

Overlevel handling is initiated at a fill level of 25 mm below the upper edge of the bath. The customer can adjust overlevel handling as required. A *low level warning* is issued at approx. 110 mm and a *low level alarm* is triggered at approx. 120 mm below the upper edge of the bath.

Circulation thermostat

The device has a filling mode for convenient filling of the heat transfer liquid.

Filling mode helps you fill the device.

1. Close the draining tap by turning it clockwise.
2. Attach a suitable hose (heat transfer liquid/temperature) to the overflow connection on the device.

3. Place the end of this hose into a suitable canister to collect the overflowing heat transfer liquid.
4. Switch on the device.

i *If filling mode is active, the symbol for the bath vessel will be flashing in the home window. The device does not heat or cool.*

- ▶ If the device is empty, *filling mode* is activated immediately after the device is switched on.

If the device is not empty, *filling mode* can be manually started. Select the *Settings* → *Filling mode* → *Start filling* menu item.

5. Remove the tank lid.
 - ▶ A screen is fitted to the filling nozzle. Do not remove the screen!
6. Carefully fill with heat transfer liquid.

i *The quantity per level is approximately 0.15 liters. With a quantity of 2.4 liters or more in the bath vessel, level 1 is displayed.*

- ▶ A signal tone with long intervals is emitted starting from around the fifth level to warn against overfilling the device. If you continue filling, the interval of the signal is shortened.

If a continuous tone sounds, the bath vessel is full. If you continue filling the device, it will overflow.

7. If the fill level (starting at level 5) is adequate, press the [Standby] softkey to start the pump and fill the connected external consuming unit.
 - ▶ Heat transfer liquid is pumped into the external consuming unit. The level of the heat transfer liquid in the bath vessel drops.

8. Replenish the heat transfer liquid.
 - ▶ If, however, the fill level drops too far, the device automatically switches to the "Low level" alarm state. The pump is switched off.

9. Add sufficient heat transfer liquid. Deactivate the alarm using the [Unlock key]. The pump automatically restarts.

10. Carry out steps 8 and 9 until the device and the connected consuming unit are filled.

11. Press [Stop filling] to exit from filling mode and deactivate the acoustic alerts.




Fig. 26: Low level alarm

i *The [filling mode] can be used to refill the device during operation.*

i *If [filling mode] is active, the device does not heat or cool. You can only start the device after you end [filling mode].*



DANGER!
Risk of hot heat transfer liquid escaping

Fire

- Degas slowly and carefully. Avoid ignition sources in the vicinity of the filling nozzle and overflow.



DANGER!
Hot heat transfer liquid in the expansion vessel

Fire

- Keep the cover of the expansion vessel closed during operation.

5.3 Changing/draining heat transfer liquid



WARNING!
Contact with hot or cold heat transfer liquid

Scalding, cold burns

- Bring the heat transfer liquid to room temperature before draining.



WARNING!
Splashing heat transfer liquid

Eye damage

- Always wear suitable safety glasses when working on the device.



Observe the regulations for the disposal of used heat transfer liquid.

1. Allow the device and heat transfer liquid to cool or warm up to room temperature.
2. Turn off the device and pull out the mains plug.
3. Attach a hose to the draining nozzle.
4. Place the hose in a suitable container to collect the heat transfer liquid.



It may be necessary to drain the device several times if the filling volume is high.



Fig. 27: Attaching hose

5. Open the draining tap by turning it counterclockwise.



Drain the bath, external consuming unit, accessories and hoses completely.

6. If necessary, clean or flush out the device (with new heat transfer liquid, for example).



After changing to a different heat transfer liquid, you may have to set new values for the temperature limit, overtemperature switch-off point and/or the controller output limit.

5.4 Establishing a mains connection



WARNING!
Contact with voltage conductors due to faulty mains cable

Electric shock

- The mains cable must not come into contact with the top of the device, hoses containing hot heat transfer liquid and other hot parts, neither during operation nor after the device is switched off.



NOTICE!
Use of impermissible mains voltage or mains frequency

Device damage

- Compare the type plate with the available mains voltage and mains frequency.

Please note the following:

- Note for electric installation on site:
 - The devices must be protected with a 16 ampere circuit breaker fitted during installation.
Exception: Devices with 13 ampere UK plugs.
- Only use the supplied power cable for the power supply.
- Only connect the device to sockets with a protective earth conductor (PE).

5.5 Switching on the device



WARNING!

Risk of contact with cold/warm parts if the operator does not realize that the device is switched on

Scalding, cold burns

- The remote control unit must be kept within visual range of the device.




Fig. 28: Home window

1. Switch on the device at the mains switch.
 - ▶ A signal tone is emitted and the operation and fault indicator LED lights up several times.
The LED then lights up green continuously when there are no faults pending.
2. The version numbers of the installed software appear on the display for about 5 seconds.
Then the home window appears.
3. The device can now be operated using the Base remote control unit.



You can now view the version numbers of the software installed on the device in the menu at any time.

5.6 Display buttons



Fig. 29: Base remote control unit

- 1 Display
- 2 Four cursor buttons
- 3 Input button
- 4 Right softkey (standby)
- 5 Left softkey (display/ESC)
- 6 Brightness sensor

The display buttons control the functions on the device.

- The up, down, right and left cursor buttons are used to navigate in the display.
- The input button is used to confirm a selection in the display or execute a command.
- The softkeys are used to execute the functions indicated on the display that are assigned to these buttons.

Key lock

The keys on the Base remote control can be locked to prevent accidental changes.

Activating

The Base remote control displays the home window.

1. Press and hold down the [input button].
2. Press and hold down the [Down] cursor button.
 - ▶ After 5 seconds, the key lock is activated.
Only the left [Display] softkey continues working.

Deactivating

1. Press and hold down the [input button].
2. Press and hold down the [Up] cursor button.
 - ▶ After 5 seconds, the key lock is deactivated.

5.7 Base remote control unit menu structure




Fig. 30: Base menu, Part 1




Fig. 31: Base menu, Part 2

Functions that cannot be executed are omitted from the menu structure.

5.8 Setting overtemperature protection Tmax



WARNING!

Risk of heat transfer liquid overheating due to incorrect entry of overtemperature switch-off point Tmax

Fire

- Set the overtemperature switch-off point to 5 K above the upper limit of the temperature range for your application. The overtemperature switch-off point must be below the flash point of the heat transfer liquid.

The maximum temperature Tmax for the overtemperature protection is set at the rotary knob using a screwdriver. The exact preset maximum temperature also appears automatically on the display.



Chapter 7.7 “Checking the overtemperature protection” on page 101



Fig. 32: Setting Tmax

This section is relevant for:

- Device operation using the Base remote control unit

1. Adjust the rotary knob using a screwdriver. Turn the knob counter-clockwise to decrease the T_{max} value.
 - ▶ The new preset maximum temperature T_{max} appears on the display.
The maximum temperature is adopted automatically, the T_{max} window is replaced by the home window after a few seconds.

5.9 Setting temperature limits T_{ih} and T_{il}

This function is used to set temperature limits T_{ih} and T_{il} . The temperature limits restrict the temperature target value. A warning is issued if the internal actual temperature is outside the temperature limit range. The temperature limits should reflect the limits of your application. A tolerance of 2 K should also be added to the upper and lower temperature limits to compensate for overshoots by the control, in particular external controls. The working temperature range of the heat transfer liquid must also be taken into consideration when defining temperature limits.

This section is relevant for:

- Device operation using the Base remote control unit

Setting T_{ih} and T_{il}

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Temp. limit values* menu items using the cursor buttons.
 - ▶ Two options appear on the display.
4. Select one of the following options:
 - Select the entry [Lo. limit T_{il}] to set the lower limit value.
 - Select the entry [Upper limit value T_{ih}] to set the upper limit value.
5. Adjust the value in the input window using the cursor buttons.
6. Press [OK].
 - ▶ The value is adopted and the input window disappears.
7. Press the [ESC] softkey to open the home window.



Fig. 33: Setting the temperature limit

5.10 Setting the temperature target value T_{set}

The temperature target value T_{set} is the temperature that the constant temperature equipment should reach and then maintain.

This section is relevant for:

- Device operation using the Base remote control unit




Fig. 34: Entering set temperature

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Press the [input button] again to select the first [Set temperature] menu item.
 - ▶ An input window appears on the display.
4. Adjust the new set temperature using the cursor buttons.
5. Press [OK] to confirm the new value.
 - ▶ The value is accepted.
6. Press the [ESC] softkey to open the home window.

5.11 Basic settings

5.11.1 Safety Mode

Purpose of Safety Mode

Safety Mode gives users of LAUDA thermostatic circulators the option of defining a safe temperature state in advance. In the event of a malfunction or error, the user can manually switch to this state quickly and easily or allow the device to do so automatically.



When Safety Mode is **active**, the thermostatic circulator continues to operate at the set temperature T_{set} and control variable previously defined in the Safety Mode menu.

In the Safety Mode submenu, the user specifies how the device should respond (actions) if certain events occur.

Which events lead to the activation of Safety Mode?

- Being activated manually via the thermostatic circulator.
- Command via interface.
- Being triggered by certain alarms.
- Communication with the control station being interrupted.

What indicates that Safety Mode is active?

- A flashing Safety Mode icon  appears on the display when the device is operating. The pump impeller and pump level number are hidden. If the device is on standby, T_{ext} is hidden and the Safety Mode icon  is displayed instead.

What happens in active Safety Mode if there is **no alarm** pending?

- The *Safety Mode* window appears on the Base display and gives you the option of quitting *Safety Mode*.

What happens in active Safety Mode if **an alarm** is pending?

- The *Alarm* window appears in the Base display. The *Safety Mode* window only appears with the option of quitting *Safety Mode* once the alarm has been acknowledged on the device.
- Special case *Overtemperature*

Activating Safety Mode using an interface command

Safety Mode can be activated using an interface command. The device is then set to a safe state.

Table 9: List of interfaces and associated interface commands

| Interface | Interface command | Description |
|-----------|-------------------|--|
| Ethernet | OUT_MODE_05_1 | Interface command activates Safety Mode. |
| RS 232 | OUT_MODE_05_1 | Interface command activates Safety Mode. |

Activating Safety Mode in the event of an alarm

The thermostatic circulator can also activate Safety Mode automatically in the event of an alarm.



Safety Mode can only become active if the Safety Mode function was activated in the menu beforehand.

Table 10: List of alarms that can be activated by Safety Mode

| Alarm | Description of action |
|--|--|
| Alarm 9 External actual value Pt is not available | Safety Mode is activated. If the parameter transfer was activated in Safety Mode, the temperature set point should be adopted from the Safety Mode parameters. External control is switched automatically to internal control. |
| Alarm 10 External actual value Analog is not available | Safety Mode is activated. If the parameter transfer was activated in Safety Mode, the temperature set point should be adopted from the Safety Mode parameters. External control is switched automatically to internal control. |
| Alarm 11 External actual value Serial is not available | Safety Mode is activated. If the parameter transfer was activated in Safety Mode, the temperature set point should be adopted from the Safety Mode parameters. External control is switched automatically to internal control. |
| Alarm 12 Current interface 1, interruption | Safety Mode is activated. Safety Mode parameters are adopted depending on the configuration. |
| Alarm 13 Current interface 2, interruption | Safety Mode is activated. Safety Mode parameters are adopted depending on the configuration. |
| Alarm 15 Fault at the digital input | Safety Mode is activated. Safety Mode parameters are adopted depending on the configuration. |
| Alarm 16 Refilling has failed | Safety Mode is activated. Safety Mode parameters are adopted depending on the configuration. |

| Alarm | Description of action |
|---|--|
| Alarm 17 Set valve to inflow | Safety Mode is activated. Safety Mode parameters are adopted depending on the configuration. |
| Alarm 18 Set valve to outflow | Safety Mode is activated. Safety Mode parameters are adopted depending on the configuration. |
| Alarm 20 External actual value from Ethernet is not available | Safety Mode is activated. If the parameter transfer was activated in Safety Mode, the temperature set point should be adopted from the Safety Mode parameters. External control is switched automatically to internal control. |

Activating Safety Mode by disconnecting from the control station

Monitoring of the control station by the thermostatic circulator can be activated in the device menu. The control station must send a command to the thermostatic circulator periodically. The user must define the time the system waits before reporting a communication fault. If the control station fails to send a command within the specified time, the interface (Ethernet or RS 232) reports a communication fault. The thermostatic circulator then switches to Safety Mode and a warning is generated.

Switch Safety Mode to standby

1. Press any button on the Base unit to display the Home window.
2. Press the [input button] to open the menu.
3. Select the *Safety Mode* menu item.

Table 11: Settings in the *Safety Mode* menu

| Menu item | Description |
|---------------|--|
| Function | <p>Here you can define whether the Safety Mode function is on standby or deactivated.</p> <p>Select one of the following options:</p> <ul style="list-style-type: none"> ■ Option <i>On</i>: The Safety Mode function is on standby. ■ Option <i>Off</i>: The Safety Mode function is deactivated. <p>If the Safety Mode functions is deactivated,</p> <ul style="list-style-type: none"> ■ Safety Mode cannot be activated via the <i>Start</i> menu item. ■ Activation by an alarm or interface is also blocked. ■ Safety Mode parameters cannot be modified. |
| Configuration | In this submenu, you can configure the parameters that the device uses when Safety Mode is active. |

| Menu item | Description |
|-------------------------|---|
| Start | Starts the Safety Mode function. The <i>Start</i> menu item only appears if Safety Mode was switched to standby with the option <i>On</i> in the <i>Function</i> submenu. |
| Control station timeout | The timeouts for the Ethernet and RS 232 interfaces are configured separately in this submenu (timeout 1 to 60 seconds, 0 = off). |

Table 12: Settings in the *Configuration* menu

| Description when Safety Mode is active | Configure the Safety Mode parameters |
|--|---|
| <i>Set point</i> : When Safety Mode is activated, the temperature of the device can be regulated to this stored value. | Enter the set point T_{set} here. |
| <i>Change set point</i> : When Safety Mode is activated, the temperature of the device is regulated to the value stored in the Set point menu. | Select one of the following options: <ul style="list-style-type: none"> ■ Option <i>Unchanged</i>: The device retains the previous set point. ■ Option <i>Change set point</i>: The temperature of the device is regulated to this stored set point T_{set}. |
| <i>Control</i> : When Safety Mode is activated, the temperature of the device is regulated to this stored value. | Select one of the following options: <ul style="list-style-type: none"> ■ Option <i>Unchanged</i>: The device retains the previous control variable. ■ Option <i>Internal Pt1000</i>: The device variable is regulated to the Internal Pt1000 control variable. |

Deactivation of active Safety Mode

If Safety Mode is active, the operator can deactivate Safety Mode using the remote control.

Deactivating Safety Mode via an interface is not possible.



If an alarm has triggered Safety Mode, the alarm on the thermostatic circulator must be reset first. Only then can Safety Mode be deactivated.

| Menu for deactivating Safety Mode | Description |
|-----------------------------------|---|
| <i>Operating parameters</i> | Safety Mode is ended. The device continues operating with the parameters (T_{st} , control variable) preset before Safety Mode was activated. |
| <i>Safety Mode parameters</i> | Safety Mode is ended. The device continues operating with the parameters (T_{set} , control variable) preset in the Safety Mode configuration. |

5.11.2 Adjusting the volume of signal tones

The device indicates alarms, warnings and errors both visually and acoustically.




Fig. 35: Adjusting volume

In this menu, you can adjust the volume of the signal tones for: errors, alarms and warnings. The volume settings are: off, low, medium and loud.

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Basic setting* → *Signal tone* menu item.
 - ▶ A list of signal tones appears.
4. Select the signal tone that you wish to change using the cursor buttons.
5. Press [OK] to confirm.
6. Select a volume setting using the cursor buttons.
7. Press [OK] to confirm.
8. Press the [ESC] softkey to open the home window.

5.11.3 Adjusting the display brightness

The Base remote control unit is fitted with a sensor that automatically adapts the display brightness to the ambient brightness. However, the display brightness can be selected manually if desired.




Fig. 36: Adjusting brightness

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Basic setting* → *Display* → *Brightness* menu item.
4. The following options are available in the input window:
 - With the standard setting *Autom.*, the brightness is adapted automatically
 - You can select the brightness manually with entries *Level 1 - 5*. The brightness intensifies from *Level 1*. The display adjusts to the selected degree of brightness immediately.
5. Press the left [cursor button], the [ESC] softkey or [OK] to exit the input window.

5.11.4 Operating mode following a power failure (auto start)

In general, the device is required to resume operation after a power failure. However, you can introduce a manual activation step for safety reasons.




Fig. 37: Selecting autostart setting

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Basic setting* → *Autostart* menu item.
4. Select one of the following options:
 - If *Off* is selected, the device is set to standby mode when switched on after a power failure.
 - If *On* is selected and a power failure occurs, the device restarts and continues operating in (*standby/operating*) mode, depending on which was selected prior to the power failure.
5. Press the [input button] to confirm.

5.11.5 Limiting the current consumption

If your mains fuse is less than 16 A, the current consumption can be reduced incrementally from 16 A to 8 A. The maximum heating power is reduced accordingly. Establish whether other consuming units or only your device is connected to the fused circuit.




Fig. 38: Current consumption setting




Fig. 39: Specifying current consumption

5.11.6 Selecting the menu language



Fig. 40: Selecting the menu language

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Basic setting* → *Current consumption* menu item.

4. Change the current consumption accordingly using the cursor buttons.
5. Press the [input button] to confirm.

The menu languages available for PRO thermostats with a Base remote control unit are German, English, French, Spanish and Italian.

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Basic settings* → *Language* menu item.
4. Select one of the available languages.
5. Press the [input button] to confirm.

6 Operation

6.1 General safety instructions



WARNING!

Risk of contact with cold/warm parts if the operator does not realize that the device is switched on

Scalding, cold burns

- The remote control unit must be kept within visual range of the device.



WARNING!

Application-specific dangers due to inadvertently confusing the remote control units for several devices located beside one another

Scalding, cold burns, fire

- Make sure you are using the correct operating unit.



CAUTION!

Contact with hot or cold surfaces

Hot and cold burns

- Do not touch the connection nozzle or draining nozzle during operation.
- In addition, the temperature of some bath cover parts may exceed 70 °C at higher operating temperatures.

The following safety notice is relevant for bath thermostats:



NOTICE!

Risk of remote control unit falling into the bath

Device damage

- The remote control unit holder must be attached securely to the device.

The following safety notices are relevant for circulation thermostats:



DANGER!

Risk of hot heat transfer liquid escaping

Fire

- Degas slowly and carefully. Avoid ignition sources in the vicinity of the filling nozzle and overflow.



DANGER!
Hot heat transfer liquid in the expansion vessel

Fire

- Keep the cover of the expansion vessel closed during operation.



WARNING!
Boiling heat transfer liquid escaping from the filling nozzle

Chemical and heat burns

- Never replenish hot heat transfer liquid with other fluids.

The following safety notices are relevant for devices containing natural refrigerant:



WARNING!
Risk of refrigerant circuit bursting

Escaping combustible refrigerant generates an explosive atmosphere

Explosion, burns, fire

- Ventilate the room thoroughly without delay.
- During this period, do not operate any switches on the device or anywhere else in the room.
- Do not ignite flames or sparks and refrain from smoking.



WARNING!
Risk of refrigerant circuit bursting from excessive ambient temperatures while device is inoperative

Impacts, cutting, device damage

- Observe the permitted storage and operating temperatures.



CAUTION!
Risk of refrigerant circuit bursting

Hazard to health when inhaled (TLV values exceeded)

- Ventilate the room thoroughly without delay.
- During this period, do not operate any switches on the device or anywhere else in the room.
- Do not ignite flames or sparks and refrain from smoking.

Please also note the following:

- The device must be taken out of operation and drained before being moved.

6.2 Operating modes

The device supports two operating modes.

- In *Operation* mode, the components of the device are operational.
- In *Standby* mode, all device component are switched off. Power is only supplied to the display on the device. This operating mode is suitable for adjusting multiple settings, for example.

A program that has been started is paused in *Standby* mode. After activating *Operation* mode, the program must be resumed again manually.

↳ Chapter 6.4 “Activating and deactivating standby and operation modes” on page 79

6.3 Setting the pump level

There are several pump levels for regulating the pumps of the bath and circulating thermostats. The different pump levels optimize bath circulation, output, conveyance pressure, noise emissions and mechanical heat input.

↳ Chapter 3.3.1 “Hydraulic circuit” on page 23



A pump level of 1 to 3 is appropriate for a small bath thermostat without an external consuming unit. A higher output level is appropriate for the circulation thermostat, in order to minimize the temperature difference between the bath and external consuming unit.




Fig. 41: Setting the pump level

1. Press any button on the Base remote control unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Pump level* menu items using the cursor buttons.
 - ▶ The pump levels appear on the display.
4. Select the desired pump level using the cursor buttons.



The selected pump level is activated automatically. It does not have to be activated separately.

5. Press the [ESC] softkey to open the home window.

6.4 Activating and deactivating standby and operation modes

In standby mode, device components such as the pump are switched off. The display remains active, however. Standby mode is ideal for adjusting multiple settings using the operating unit.




Fig. 42: Standby home window

1. Press any button on the Base unit to display the home window.
2. Press the [Standby] softkey.
 - ▶ The device is now in standby mode. Standby appears at the top of the display.
3. Press the [Standby] softkey.
 - ▶ The device starts to operate again. The word Standby disappears from the display.

6.5 Defining the actuating signal limit

The maximum heating output can be limited using the actuating signal limit. The limit is set as a percentage of the maximum value.

The controller output limit for the heating output is designed to prevent excessive temperatures on the surface of the heater. Excessive heater temperatures may degrade the heat transfer liquid or damage the device.

1. Press any button on the Base unit to display the Home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Control* → *Actuating variable* menu item.
4. Select [Max. heating] and press [OK] to confirm.
 - ▶ An input window appears. The controller output limit can be set to a value within the limit values displayed.
5. Change the value accordingly.
6. Press the [OK] button to return to the previous screen with the new setting configured.
 - ▶ The new setting is active.



Set the controller output limit before adjusting the control parameters.

6.6 External control

6.6.1 Activating external control, deactivating internal control

If you want the device to regulate to another control variable, you must set a new control variable. The old control variable is then deactivated automatically.

Connect a Pt100 temperature probe for monitoring the temperature in the external consumer to the **10S interface** on the thermostatic circulator. The standard indicator for the external measured temperature T_{ext} is always the preset external control variable. If the remote control displays a different temperature, this must be set explicitly.

If the external control is activated, the thermostatic circulator regulates the temperature to the external temperature value T_{ext} and not to the bath temperature T_{int} (bath thermostat) or the outflow temperature T_{int} (circulation thermostat).

Activating the external control




Fig. 43: Activating the external control

1. Connect an external Pt100 temperature probe to the 10S interface on the thermostatic circulator.
2. Insert the Pt100 temperature probe into the heat transfer liquid in the external consuming unit and secure carefully.
3. Press any button on the Base unit to display the Home window.
4. Press the [input button] to open the menu.
5. Select the *Settings* → *Control* → *Controlled variable* menu items using the cursor buttons.
 - ▶ The options appear on the display.
6. Select the option [External Pt100] using the cursor buttons.
 - ▶ The new setting is marked with a check mark.
7. Press the [ESC] softkey to open the home window.

Activating the internal control



Select the option [Internal] in the [Control variable] submenu to activate the internal control again.

6.6.2 Setting the set point offset

It is possible to apply an offset value to the temperature measured by an external temperature probe and then process this temperature as a target value. The set point for the bath temperature can therefore be set, for example, to 15 K below the temperature of a reactor measured by the external temperature probe.

Navigating to the settings

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Control* → *Setpoint offset* menu items using the cursor button and input button.
4. Select one of the following options:
 - [Offset source] allows you to select the source used to measure the offset.
 - [Diff. set/actual value] allows you to enter the value for the set point offset.

Entering the offset value

1. Select the [Diff. set/actual] button in the Set point offset menu.
 - ▶ An input window appears. An offset value can be entered within the limit values displayed.




Fig. 44: Entering the offset value

Activating an offset source




Fig. 45: Offset source menu

2. Enter the set point offset.
3. Press the [input button] to confirm.
4. The software returns to the previous Set point offset menu.

You can activate or deactivate the value entered for the set point offset of a corresponding source using the options in the [Offset source] menu. [External Pt100], for example, allows you to activate the set point offset for the external temperature probe.

1. Select the [Offset source] button in the Set point offset menu.
2. Select one of the following options:
 - Select [Off] to deactivate the offset source.
Activate an offset source from the remaining options:
 - [External Pt100]
 - [External analog]
 - [External serial]
 - [External USB]
 - [External Ethernet]
3. Press the [input button] to confirm.
4. Press the [ESC] softkey to open the home window.

6.7 Programmer

6.7.1 Basic information

The programmer allows you to save a temperature-time program. A program consists of several temperature-time segments. A segment contains specifications relating to program replays, temperature, duration, pump level, control variable and behavior of the switching outputs. Ramps, temperature jumps and temperature maintenance phases are possible.

1. Press any button on the Base unit to display the Home window.
2. Press the [input button] to open the menu.
3. Select the *Programmer* menu item using the cursor buttons.
 - Ramp
A ramp is defined by the specified duration between the start and the end of the segment, and by the destination temperature, i.e. the temperature at the end of the segment.
 - Temperature jump
If a time is not specified (time is 0), the end temperature is reached as quickly as possible.
 - Temperature maintenance phase
No temperature change (i.e. the temperatures at the start and the end of a segment have remained identical).



The total number of freely programmable segments in the program is 50.

Available settings

| | Tend | hh | mm | Tol. |
|---|-------|----|-----|------|
| 1 | 23.00 | -- | -- | 0.0 |
| 2 | 20.00 | 0 | :0 | 0.1 |
| 3 | 30.00 | 0 | :10 | 0.0 |

ESC | New | Delete

Fig. 46: Editing a program

| Setting | Description |
|------------|---|
| --- | Program segment number |
| Tend | End temperature that should be reached |
| hh | Time in hours (hh) by which the specified temperature should be reached |
| mm | Time in minutes (mm) by which the specified temperature should be reached |
| Tol. | Tolerance defines how close the temperature should be to the set temperature before the next segment is processed. 0.00 means that there is no tolerance. In other words, the program focuses on the next temperature when the specified time elapses. |
| Pmp | Pump level that should be used when processing the segment. |
| S1, S2, S3 | Switching contacts on the contact module (if available) can be programmed here. Contact modules are available as an accessory. |

Editing program examples




Fig. 47: Program example

The graph shows an example of a reprogrammed set temperature profile.

The cooling time in the graph varies depending on the device type, consuming unit and so on. In example segment number 2, 50 °C should be reached within 20 minutes.

The original values in the first table below (before) are represented by a solid line, while the values in the edited profile in the second table (after) are represented by a dashed line.

Segment 1: Start

Each program starts with segment 1, which determines the temperature at which segment 2 continues the program. The temperature of segment 1 is reached as quickly as possible. It is not possible to specify a time limit for segment 1. On thermostats without cooling, the selected start temperature must be higher than the current bath temperature at the time the program starts. Without the segment 1 segment, segment 2 would be different depending on the bath temperature at program start.

Table 13: Program example, before (—)

| Before (—) | | | | | | | | |
|------------|-----------|----|----|------|-----|-----|-----|-----|
| | Tend | hh | mm | Tol. | Pmp | S1 | S2 | S3 |
| 1 | 30.0 0 | -- | -- | 0.1 | 2 | off | off | off |
| 2 | 50.0 0 | 0 | 20 | 0.0 | 2 | off | off | off |
| 3 | 70.0 0 | 0 | 40 | 0.0 | 3 | off | off | off |
| 4 | 70.0 0 | 0 | 10 | 0.1 | 4 | off | off | off |
| 5 | 60.0 0 | 0 | 30 | 0.0 | 2 | off | off | off |
| 6 | 30.0 0 | 0 | 0 | 0.0 | 2 | off | off | off |

In the edited table, a new segment with the number 3 has been entered. The time and the pump level for segment 4 have also been modified. The tolerance and pump level for segment number 5 have been adapted.

Table 14: Program example, after (- - - dashed line, edited)

| After (- - -, edited) | | | | | | | | |
|-----------------------|-----------|----|----|------|-----|-----|-----|-----|
| | Tend | hh | mm | Tol. | Pmp | S1 | S2 | S3 |
| 1 | 30.0 0 | -- | -- | 0.1 | 2 | off | off | off |
| 2 | 50.0 0 | 0 | 20 | 0.0 | 2 | off | off | off |
| 3 | 50.0 0 | 0 | 20 | 0.1 | 3 | off | off | off |
| 4 | 70.0 0 | 0 | 20 | 0.0 | 4 | off | off | off |
| 5 | 70.0 0 | 0 | 10 | 0.8 | 2 | off | off | off |

| After (---, edited) | | | | | | | | |
|---------------------|-----------|---|----|-----|---|-----|-----|-----|
| 6 | 60.0 0 | 0 | 30 | 0.0 | 2 | off | off | off |
| 7 | 30.0 0 | 0 | 0 | 0.0 | 2 | off | off | off |

Tolerance

Note the following and see Fig. 48:

- The Tolerance field ensures strict compliance with the residence time at a specific temperature, for example.
- The subsequent segment is only processed when the actual temperature reaches the tolerance range (1) so the ramp in the second segment is delayed and only starts at 2, for example.
- Selecting a tolerance range that is too small can cause undesired delays. In extreme cases, it may not be possible to continue the program. The selected tolerance range should not be too small, **especially if the control is external**. A greater tolerance has been entered for segment 5 to guarantee adherence to the required time of 10 minutes, even with transient responses (3).
- A tolerance range should only be programmed for flat (slow) ramps, if appropriate. Steep ramps that come close to the maximum possible heating-up or cooling rates of the device may be severely delayed (4) if the tolerance range is too small (in segment 2 here).




Fig. 48: Target/actual program process

The above graph of the edited process illustrates the possible delay in the development of the actual temperature in the bath vessel (solid line) in relation to the set temperature of the program encoder (gray area).

6.7.2 Starting, interrupting, continuing and ending a program

1. Press any button on the Base unit to display the Home window.
2. Press the [input button] to open the menu.




Fig. 49: Defining the program status

3. Select the *Program encoder* → *Edit* menu items using the cursor buttons.

- ▶ The program appears on the display and you can now edit it.

1. Select the [Status] menu item in the Program encoder menu.

2. The following options are available:

- Select the option [Start] to start the program.
- Once the program has started, you can press [Hold] to pause it.
- A paused program can be continued by pressing [Continue].
- Select the option [Stop] to end the program.
- You can pause the program encoder by pressing the [Standby] softkey. Once standby mode is deactivated, the program encoder continues to operate in the previously selected mode (pause or active operation).

6.8 Control parameters

Various control parameters for operation of the different PRO thermostat product types have been set ex works. These control parameters are optimized and installed with water as a heat transfer liquid for internal and external control.

- It may be necessary to adapt the configuration on a case by case basis, depending on the application.
- The heating capacity and viscosity of the different heat transfer liquids influence the control behavior.



Only modify the control parameters if you possess adequate knowledge of control system engineering.

6.8.1 Control basics

Definition

A brief explanation of terms

| | |
|--------------------------|--|
| Actuating signal | - Initial value of the controller to compensate for the difference between the actual value and target value (control deviation). |
| PID controller | - The PID controller operates with extreme speed and precision and consists of a P, I and D-component. |
| Proportional range X_p | - The proportional range X_p indicates the temperature range within which the proportional component (P-component) of the controller represents 0 – 100 % of the maximum actuating signal. If the preset X_p is 10 K and the control deviation is 2 K, for example, the P-component is 20 % of the actuating signal. If the control deviation is 10 K or more, the P-component is 100 % of the actuating signal. |
| Adjustment time T_n | - The adjustment time is crucial for the I-component of the actuating signal. It specifies the interval at which an existing control deviation is integrated. The higher the T_n , the slower the control deviation is integrated and the more sluggish the control becomes. A small T_n makes the control more dynamic and eventually results in vibrations. |
| Hold-back time T_v | - The D-component of the actuating signal is formed from the hold-back time T_v . It influences the speed with which the actual value approaches the target value and counteracts the P-component and I-component. The greater the preset hold-back time T_v , the more intensively the output signal is attenuated. Rule of thumb: $T_v = T_n \times 0.75$. |
| Attenuation time T_d | - Attenuation time of the D-component. Rule of thumb: $T_d = T_v \times 0.15$. |
| Correction limitation | - Represents the maximum permitted deviation between the temperature at the external consuming unit and the temperature at the outlet. |

Optimizing the hydraulic system

One important prerequisite for an acceptable control quality is a well designed hydraulic system. The best possible connection must therefore be established between the temperature control application and the constant temperature equipment.

- Use short hoses with a large cross section to reduce the flow resistance. More heat transfer liquid can circulate in a short time, resulting in a shorter circulation time.
- Select the thinnest possible heat transfer liquid with the highest possible heating capacity. Precedence list: Water, water-glycol, oils, Fluorinert®.
- Select the highest possible pump level.
- For external applications, set the flow rate through the external consuming unit as high as possible.
- With bath thermostats, make sure that the circulation in the bath is adequate.

Effects of viscosity on the heat transfer liquid

A control that is stable at low temperatures will usually be stable at high temperatures. Conversely, if a system is just about stable at high temperatures, it will most probably be unstable at lower temperatures, i.e. vibrate.

The viscosity of the heat transfer liquid changes drastically with the temperature. At low temperatures, liquids are more viscous. The control quality is therefore generally poorer at low temperatures. For this reason, the control setting should be towards the lower end of the temperature range.

If the temperature range of an application is -20 to 80 °C, for example, a control setting of -10 to 20 °C is most suitable.

Influence of control parameters on the control behavior






Fig. 50: Ideal setting



If the X_p parameter selected is too large, the actual value will reach the proportional range early and the P-component will be less than 100 % of the actuating signal. It takes longer to reach the target value and as a result, the simultaneously integrated I-component has more time to establish its actuating signal component. Once the target value is reached, the excessive addition of the I-component causes the value to overshoot the target value. If proportional range X_p is reduced, the P-component remains at 100 % for longer. Consequently, the actual value approaches the target value more quickly and the I-component has less time to integrate the system deviation. The overshoot is reduced.

Fig. 51: Control parameter X_p too large



If the proportional range selected is too small, the P-component of the actuating signal remains at 100 % for a long time. This value decreases even faster within the proportional range, i.e. the actuating signal decreases rapidly and the progress of the actual value towards the target value comes almost to a complete stop. The I-component, which only becomes effective now, causes the actual value to move slowly towards the target value.

Fig. 52: Control parameter X_p too small




Fig. 53: Control parameters T_n and T_v too small

In the case shown here, the preset I-component is too large (parameter T_n too small, T_n must be increased). The I-component integrates the control deviation until it becomes 0. If integration proceeds too rapidly, the actuating signal, i.e. the output signal of the controller, is too large. As a result, the actual value fluctuates (fading) around the target value. The hold-back time (parameter T_v) should be adapted using the formula: $T_v = T_n \times 0.75$.



Fig. 54: Control parameters T_n and T_v too large

The actual value increases relatively sharply towards the specified target value. The proportional area settings seem to be correct. If the control deviation becomes smaller, the actual value approaches the target value much more slowly. The integration component (I-component) must compensate for the drastic reduction of the proportional component (P-component). In this case, the I-component is integrated too slowly. The parameter T_n , which specifies the integration interval, must therefore be reduced. The hold-back time (parameter T_v) should be adapted using the formula: $T_v = T_n \times 0.75$.

6.8.2 Overview of internal control parameters

The internal control compares the set temperature T_{set} with the bath temperature T_{int} and calculates the actuating signal, i.e. the measurement used for heating or cooling.

| Designation | Abbreviation | Unit |
|--------------------|--------------|------|
| Proportional range | X_p | K |
| Adjustment time | T_n | s |
| Hold-back time | T_v | s |
| Attenuation time | T_d | s |



If T_v manual/auto is set to auto, T_v and T_d cannot be modified. In this case, they are derived with fixed factors of T_n .

The following parameters may also influence the internal control:

- Temperature limits: T_{il} and T_{ih} ↪ Chapter 5.9 “Setting temperature limits T_{ih} and T_{il} ” on page 70
- Controller output limit: Heating power and cooling capacity ↪ Chapter 6.5 “Defining the actuating signal limit” on page 80

6.8.3 Overview of external control parameters

The control system for the external actual value is designed as a 2-stage cascade controller to improve guidance behavior and consists of a guide controller (external controller) and a slave controller (internal controller). The temperature of the relevant consuming unit T_{ext} is also required. This temperature is measured using an external Pt100 temperature probe or an interface for importing the actual temperature.

The guide controller compares the set temperature T_{set} with the external temperature in the consuming unit T_{ext} and uses these temperatures to calculate the set temperature (set_internal) for the slave controller (internal controller).

The slave controller compares the set temperature (set_internal) with the outlet temperature and calculates the actuating signal, i.e. the measurement used for heating or cooling.

Correction limitation

If set temperature T_{set} indicates a temperature jump, the control may set an outlet temperature much higher than the temperature T_{ext} required in the external container. Therefore, there is a correction limitation that specifies the maximum permitted deviation between the temperature at the output T_{int} and the temperature in the external consuming unit T_{ext} .

Control parameters on the guide controller

The following control parameters can be set on the guide controller (PID₁ controller or external controller).

| Designation | Abbreviation | Unit |
|----------------------|-----------------|------|
| Amplification factor | K _{pe} | - |
| Proportional range | Prop_E | K |
| Adjustment time | T _{ne} | s |
| Hold-back time | T _{ve} | s |
| Attenuation time | T _{de} | s |

Control parameters on the slave controller

The following control parameters can be set on the slave controller (P-controller).

| Designation | Abbreviation | Unit |
|--------------------|-----------------|------|
| Proportional range | X _{pf} | K |



If Tv manual/auto is set to auto, T_{ve}, T_{de} and Prop_E cannot be modified. In this case, they are derived with fixed factors of T_{ne}. Prop_E is a constant predefined value here.

The following parameters may also influence the external control:

- Temperature limits: T_{il} and T_{ih} ↪ Chapter 5.9 “Setting temperature limits T_{ih} and T_{il} ” on page 70
- Controller output limit: Heating power and cooling capacity ↪ Chapter 6.5 “Defining the actuating signal limit” on page 80
- Correction limitation ↪ “Correction limitation” on page 90

6.8.4 Opening the control menu

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Control* menu items using the cursor button and [OK].

6.8.5 Editing internal control parameters



If you require the controller output limit, set it before adjusting the control parameters. ↪ Chapter 6.5 “Defining the actuating signal limit” on page 80

The internal control in the device is active. Refer to ↪ Chapter 6.6.1 “Activating external control, deactivating internal control” on page 80 for information on reconfiguring the control.

Adjusting control parameters manually or automatically

The [Tv man/auto] menu item allows you to define whether the control parameters [Tv] and [Td] are adapted manually or configured automatically. If the automatic setting is enabled, both control parameters are marked with the letter "a" and a lock symbol and cannot be selected. In this case, [Tv] and [Td] are derived with fixed factors of [Tn].




Fig. 55: Tv man/auto

1. Select the *Control parameters* → *Internal* menu item in the Control menu.
2. Select the *Tv man/auto* menu item in the menu.
3. Press the [input button] to confirm the selection.
 - ▶ The manual or automatic setting for the Tv and Td control parameters is immediately active.

Editing control parameters




Fig. 56: Internal control parameter menu



Fig. 57: Adapting control parameters Xp

6.8.6 Editing external control parameters

1. Select the *Control parameters* → *Internal* menu item in the Control menu.
2. Select a control parameter.

3. Press the [input button] to confirm the selection.
 - ▶ An input window appears. A value can be entered within the limit values displayed.
4. Change the value accordingly.
5. Press the [input button] to confirm.

If you require the controller output limit, set it before adjusting the control parameters. ↪ Chapter 6.5 “Defining the actuating signal limit” on page 80

The external control in the device is active. Refer to ↪ Chapter 6.6.1 “Activating external control, deactivating internal control” on page 80 for information on reconfiguring the control.

Adjusting control parameters manually or automatically




Fig. 58: Tv man/auto

The [Tv man/auto] menu item allows you to define whether the control parameters [Tve], [Tde] and [Prop_E] are adapted manually or configured automatically. If the automatic setting is enabled, all three control parameters are marked with the letter "a" and a lock symbol and cannot be selected. In this case, [Tve] and [Tde] are derived with fixed factors of [Tne].

1. Select the *Control parameters* → *External* menu item in the Control menu.
2. Select the *Tv man/auto* menu item in the menu.
3. Press the [input button] to confirm the selection.
 - ▶ The manual or automatic setting for the Tve, Tde and Prop_E control parameters is immediately active.

Editing control parameters




Fig. 59: External control parameter menu



Fig. 60: Adapting control parameters Kpe

6.9 Calibrating the temperature probe

1. Select the *Control parameters* → *External* menu item in the Control menu.
2. Select a control parameter.
3. Press the [input button] to confirm the selection.
 - ▶ An input window appears. A value can be entered within the limit values displayed.
4. Change the value accordingly.
5. Press the [input button] to confirm.



A calibrated reference thermometer with the desired level of accuracy is necessary. Otherwise you should not change the calibration of your constant temperature equipment.

If, when checking the temperature in a steady state, you discover a constant temperature deviation of T_{int} or T_{ext} from the reference thermometer, this can be equalized via the *Calibration* menu point.

With the menu point *Offset* (1-point comparison), the characteristic of the temperature switch is adjusted in parallel by the input value.

With the menu point *2-point calibration* (2-point comparison), the characteristic of the temperature switch is adjusted and the slope of the characteristic is changed.



It is possible to change the temperature values T_{int} and T_{ext} within a range of ± 3 K respectively.

Offset

- For internal bath applications, the reference thermometer must be hung into the bath according to the specifications on the calibration certificate.
 - For external applications, the reference thermometer must be installed in the inlet of the device according to the specifications on the calibration certificate.
 - To measure the temperature, wait until the system is in a steady state.
1. Press any button in the Home window of the Base unit to display the menu bar.
 2. Press the [input button] to open the menu.

3. Using the cursor key and enter key, select the menu points *Settings* → *Calibration* → *internal Pt1000* or → *external Pt100* → *Offset*.
 - ▶ An input window opens.
4. Enter the temperature value read off the reference thermometer into the Base unit.
5. Press enter to confirm the new value.
 - ▶ The new value has been accepted.

2-point calibration

- For internal bath applications, the reference thermometer must be hung into the bath according to the specifications on the calibration certificate.
 - For external applications, the reference thermometer must be installed in the inlet of the device according to the specifications on the calibration certificate.
 - The upper and lower temperature value must be at least 40 K apart.
 - To measure the temperature, wait until the system is in a steady state.
1. Set a low T_{set} set point on the device.
 2. Wait until the set point and the temperature of the heat transfer liquid have equaled out.
 3. Press any button in the Home window of the Base unit to display the menu bar.
 4. Press the [input button] to open the menu.
 5. Using the cursor key and enter key, select the menu points *Settings* → *Calibration* → *internal Pt1000* or → *external Pt100* → *2-point upper*.
 - ▶ An input window opens.
 6. Enter the temperature value read off the reference thermometer into the Base unit.
 7. Press enter to confirm the new value.
 - ▶ The lower value has been accepted.
 8. Set a high T_{set} set point on the device.
 9. Wait until the set point and the temperature of the heat transfer liquid have equaled out.
 10. Select the menu point [2-point upper] in the *Calibration* menu.
 11. Enter the temperature value read off the reference thermometer into the Base unit.
 12. Press enter to confirm the new value.
 - ▶ The upper value has been accepted. 2-point calibration has been completed.

Restore factory calibration

Use this menu item to restore the calibration configured in the factory.

1. Press any button in the Home window of the Base unit to display the menu bar.
2. Press the [input button] to open the menu.

3. Using the cursor key and enter key, select the menu points *Settings* → *Calibration* → *internal Pt1000* or → *external Pt100* → *Factory Calibration*.
4. Select the option [yes].
5. Press [OK] to confirm the selection.
 - ▶ This deletes the customer's calibration and restores the calibration as it was configured in the factory.

6.10 Viewing the device status




Fig. 61: Device status

Reading out error memory




Fig. 62: Error memory

Displaying the product line and device type

1. Press any button on the Base unit to display the home window.
2. Press the [input button] to open the menu.
3. Select the *Settings* → *Device status* menu items using the cursor buttons.
 - ▶ The device status menu appears.
4. The following options are available:
 - Read out error memory
 - View device data
 - View software version
 - View device type
 - View serial number

Each device has an error memory for storing up to 140 warning, error and alarm messages that can be used to analyze errors.

1. Select the menu item *Device status* → *Errorstore*.

i The most recent message appears in the first position. The message text is displayed in the footer.

2. You can navigate through the list using the up and down arrow buttons.

The following information is displayed for each message:

- The relevant module that triggered the message is displayed under *Source*.
- *Code* is the encoded description of the alarm, warning or error.
- *Type* specifies whether it is an alarm, warning or error.

The product line and device type are displayed directly on the menu item in the device status menu. It is not possible to modify settings here.

Viewing device data

LAUDA Service uses this display for diagnostic purposes. It is not possible to modify settings here.




Fig. 63: Device data

1. Select the *Device data* menu item in the Device status menu.
 - ▶ Various device parameters are displayed.

Displaying the software version

The relevant versions of the installed software are required for on-site service visits and telephone support.




Fig. 64: Display of software versions

1. Select the [SW version] menu item in the Device status menu.
 - ▶ The software versions installed on the device are displayed. The software versions of any connected solenoid valves are also displayed.

Displaying the serial numbers

The serial numbers are required for on-site service visits and telephone support.




Fig. 65: Serial numbers

1. Select the [Serial numbers] menu item in the Device status menu.
 - ▶ The serial numbers of the control system, cooling system and Base remote control unit are displayed.

7 Maintenance

7.1 General safety instructions



DANGER!
Contact with live or moving parts

Electric shock, impacts, cutting, crushing

- The device must be disconnected from the mains power supply before any kind of maintenance is performed.
- Only skilled personnel are permitted to perform repairs.



WARNING!
Malfunctions on the overtemperature protection or low-level protection are not detected

Burns, scalding, fire

- Check the Tmax function and low-level protection on a regular basis.



CAUTION!
Contact with hot or cold device parts, accessories and heat transfer liquid

Scalding, hot or cold burns

- Allow device parts, accessories and heat transfer liquid to reach room temperature before touching.

The following safety notices are relevant for devices containing natural refrigerant:



WARNING!
Risk of mechanical damage to refrigerant circuit

Explosion, fire

- Only trained personnel permitted to perform service work.
- Ventilate the room thoroughly without delay.
- During this period, do not operate any switches on the device or anywhere else in the room.
- Do not ignite flames or sparks and refrain from smoking.



WARNING!
Risk of refrigerant escaping from refrigerant circuit

Explosion, fire

- Before decommissioning the device or if there is a risk of freezing, drain the refrigerant circuit on the refrigerating machine using compressed air or an industrial vacuum cleaner (watertight). Blow compressed air through the circuit.

7.2 Maintenance intervals

The maintenance intervals described in the following table must be observed. The following compulsory maintenance tasks must be performed before operating the device for prolonged periods.

| Interval | Maintenance work |
|-------------|---|
| Weekly | Perform an external visual inspection of the drainage system for leaks |
| Monthly | Inspect the external condition of the device |
| | Inspect the external hoses for material fatigue |
| | Clean the air-cooled condenser |
| | Clean the dirt trap |
| | Check the overtemperature protection |
| Quarterly | Check the low-level protection |
| | Descale the refrigerating machine and the cooling coil (a shorter interval must be selected, depending on the water hardness and operating period) |
| Six monthly | Check the heat transfer liquid |

7.3 Cleaning the device



WARNING!
Risk of cleaning agent entering the device

Electric shock

- Only use a slightly damp cloth to clean the device.

Please also note the following:

- Only use water and detergent to clean the operating unit. Do not use acetone or solvent as these substances will permanently damage the plastic surfaces.
- Ensure that the device is decontaminated after coming into contact with hazardous materials.

- It is forbidden to use decontaminants or cleaning agents that may react with parts of the device or materials contained in those parts and potentially pose a **hazard**.
- We recommend using ethanol as a decontaminant. If you are unsure whether decontaminants or cleaning agents are compatible with parts of the device or the materials contained in those parts, please contact LAUDA Service Temperature control devices.

7.4 Cleaning the air-cooled condenser

This section is relevant for:

- Air-cooled cooling thermostats



WARNING!
Risk of mechanical damage to refrigerant circuit

Explosion, fire

- Do not use pointed objects to clean the condenser.



CAUTION!
Contact with sharp slats on the condenser

Cutting

- Clean the condenser using suitable resources such as a hand brush or compressed air.



Fig. 66: Removing/attaching the front panel

1. Switch off the device.
2.
 - Cooling circulation thermostat
To remove the front panel from the circulation thermostat, grasp the bottom of the panel with both hands and pull it towards you. Remove the front panel slowly and carefully to avoid damage.
 - Cooling bath thermostat
To remove the front panel from the bath thermostat, grasp the top of the panel with both hands and pull it towards you. Remove the front panel slowly and carefully to avoid damage.



The front panel is retained in position by four magnetic catches.

3. Sweep the slats on the condenser clean using a hand brush. Alternatively, use a vacuum cleaner to clean the slats.
4. Install the front panel again with care.

7.5 Cleaning the water-cooled condenser

The cooling water circuit and dirt trap must be cleaned regularly to maintain maximum cooling output.

Cleaning the dirt trap




Fig. 67: Counter nuts on the cooling water nozzles



Fig. 68: Dirt trap installed, with pliers

Descaling the cooling water circuit




Fig. 69: Descaling

1. Switch off the device at the mains switch.
2. Detach the cooling water hose from the cooling water supply intake.
Leave the hose on the cooling water outlet (OUT) attached securely to the device.
3. Allow compressed air to flow through the cooling water hose towards the device. Wait until all the water has flowed out of the device before detaching the compressed air supply.
4. Loosen the counter nut on the water cooling intake (IN) of the device by hand. Unscrew the counter nut from the nozzle.



If the nut is stiff, counter the hexagon bolt with pliers.

5. Detach the supply hose from the device.
6. Unscrew the dirt trap from the intake nozzle.



Use flat nose pliers to do this.

7. Clean the dirt trap and then screw back into the thread on the intake nozzle.
8. Screw the hose back onto the intake nozzle with the counter nut.
9. Screw the counter nut hand-tight.

1. Switch off the device at the mains switch and prepare for the descaling process accordingly.



Add descaler to the water cooling circuit via the intake using a pump or funnel. The descaler flows back out through the water cooling return hose and into a container with a sufficient volume (approx. 15 liters).



LAUDA descaler is required for the descaling process (order number LZB 126, 5 kg per pack). Read the safety information and instructions on the packaging before using the chemicals.

2. Detach the cooling water hose from the cooling water supply intake.
3. Detach the cooling water hose from the cooling water supply return.
4. Place the loose end of the return hose into the container.
5. Fill the water cooling supply hose with LAUDA descaler (pump or funnel).

6. Continuously top up or recirculate the descaler. Continue this process until the foaming reaction had subsided. This usually takes 20 to 30 minutes.
7. Then drain the condenser using compressed air.



Refer to ↗ “Draining the water-cooled condenser” on page 101 for detailed information on draining the condenser

8. Rinse the device thoroughly with fresh water.



Make sure a minimum of 10 liters of water flows through the system.

9. You can now connect the device back to the cooling water supply.

Draining the water-cooled condenser




Fig. 70: Cooling water connection socket

1. Switch off the device at the mains switch.
2. Detach the cooling water hose from the cooling water supply intake. Leave the hose on the cooling water outlet (OUT) attached securely to the device.
3. Allow compressed air to flow through the cooling water hose towards the device. Wait until all the water has flowed out of the device before detaching the compressed air supply.

7.6 Checking the heat transfer liquid

Contaminated or degenerated heat transfer liquid must be replaced. Continued use of the heat transfer liquid is only permitted following successful testing. The heat transfer liquid must be tested as outlined in DIN 51529.



CAUTION!
Contact with hot/cold heat transfer liquid

Scalding, cold burns

- Bring the heat transfer liquid to room temperature for analysis.

7.7 Checking the overtemperature protection

The device must be switched off if the bath temperature exceeds the maximum temperature [T_{max}]. The electronics system switches off the device components.




Fig. 71: Overtemperature alarm

1. Turn on the device.
2. Press any button on the Base unit to display the home window.
3. Use the rotary knob to slowly decrease the maximum temperature [Tmax] to a few °C above the bath temperature Tint.
 - ▶ The new preset maximum temperature Tmax appears on the display.

The maximum temperature is adopted automatically, the Tmax window is replaced by the home window after a few seconds.
4. Now adjust the set temperature [Tset] higher than the maximum temperature Tmax. Press [OK] to confirm the set temperature.
 - ▶ The device heats up beyond the maximum temperature. The device switches off when the maximum temperature is exceeded. The visual operation and fault indicator (LED) flashes red. Standby appears at the top of the display.
5. Set the correct maximum temperature again using the rotary knob.
 - ▶ The new preset maximum temperature Tmax appears on the display.

The maximum temperature is adopted automatically, the Tmax window is replaced by the home window after a few seconds.
6. Press the [red button] to unlock. This button is located on the back or side of the device, depending on the device.
 - ▶ The red light goes out. The signal tone is turned off. The device starts to operate again.

7.8 Checking the low-level protection

A double alarm signal sounds before the liquid level decreases so much that the heater is no longer covered completely with liquid. *Low level* appears on the display. The electronics system switches off the device components.



WARNING!
Contact with hot or cold heat transfer liquid

Scalding, cold burns

- Bring the heat transfer liquid to room temperature before draining.



An alarm must sound as soon as the minimum level is reached.

Levels 9 to 0 are displayed.

1. Turn on the device and the pump. Set the bath temperature to room temperature.
2. Reduce the bath level by draining heat transfer liquid from the draining nozzle.
 - ▶ The display shows the drop of the heat transfer liquid.

If the liquid falls below level 1, the device switches off and the message *Alarm* appears on the display. The visual operation and fault indicator (LED) flashes red.
3. Top up the heat transfer liquid.
 - ▶ The liquid level rises on the display.
4. Press the [red button] to unlock. This button is located on the back or side of the device, depending on the device.
 - ▶ The red LED goes out. The signal tone is turned off.




Fig. 72: Low level alarm

8 Faults

8.1 Alarms, warnings and errors

All alarms, error messages and warnings triggered on the device appear in text form on the display.

Procedure in event of alarm

Alarms affect safety. The heater is switched off and the visual operation and fault indicator (LED) flashes red. The device emits a two-tone acoustic signal. Once the cause of the fault has been eliminated, the alarm can be lifted by pressing the red unlock button. This button is located on the back or side of the device, depending on the device.

Refer to [↗ Chapter 8.2 “Alarms”](#) on page 104 for a list of alarms.

Procedure in event of warning

Warnings do not have a significant effect on safety. The device continues to operate. The device will momentarily emit a warning tone. Warnings are issued periodically. Once the cause of the fault has been eliminated, you can acknowledge the warnings on the Base or Command Touch remote control unit.

Refer to [↗ Chapter 8.3 “Control system warnings”](#) on page 105 and [↗ Chapter 8.4 “Safety system warnings”](#) on page 106 for a list of warnings.

Procedure in event of error

If an error occurs, the device emits a two-tone acoustic signal.

If this happens, switch off the device at the mains switch. If the error occurs again after the device is switched back on, note down the error message together with the detailed code. Then contact **LAUDA Service Temperature control devices**. You will find the contact information here [↗ Chapter 13.4 “Contact LAUDA”](#) on page 124.



The error messages appear on the device display together with a detailed code and a consecutive number in the sequence in which they occurred.

8.2 Alarms

| Message | Description |
|--------------------|--|
| Low level | Pump detects a low level (pump speed too high) |
| Low level | Float detects low level |
| Overtemperature | Overtemperature ($T > T_{max}$) |
| Pump blocked | Pump blocked (pump stopped) |
| Base/Command comm. | Base remote control missing or withdrawn during operation. |

| Code | Message | Description |
|------|--------------|--|
| AI 1 | T ext Pt100 | External actual value, Pt100 is not available. |
| AI 2 | T ext analog | External actual value, analog signal is not available. |

| Code | Message | Description |
|-------|---------------------------|---|
| AI 3 | Text serial | External actual value of serial interface is not available. |
| AI 4 | Input Analog 1 | Analog module: Current input 1, interruption. |
| AI 5 | Input Analog 2 | Analog module: Current input 2, interruption. |
| AI 7 | Digital Input | Fault on the digital input/switching contact |
| AI 12 | Text Ethernet | No actual value message via the Ethernet module |
| AI 14 | Communication interrupted | Communication interrupted on the interface module |

8.3 Control system warnings



All warnings start with the prefix 0. Two numbers will follow the prefix. These numbers can be found in the following table.

| Code | English Edition | Description |
|------|-------------------|---|
| 01 | CAN OVERFLOW | Overflow at CAN reception |
| 02 | WATCHDOG RESET | Watchdog reset |
| 03 | TIL LIMIT | til limit active |
| 04 | TIH LIMIT | tih limit active |
| 05 | HS OVERHEAT | Heater has overheated |
| 06 | FREE 5 | |
| 07 | FREE 6 | |
| 08 | INVALID PARAMETER | Invalid parameter in the memory |
| 09 | UNKNOWN NODE | Unknown CAN node module connected |
| 10 | OLD SWV R | Control system software version is too old |
| 11 | OLD SWV S | Protection system software version is too old |
| 12 | OLD SWV B | Operating system software version is too old |
| 13 | OLD SWV T | Temperature control system software version is too old |
| 14 | OLD SWV A | Analog module software version is too old |
| 15 | OLD SWV RS232 | RS232 module software version is too old |
| 16 | OLD SWV D | Digital module software version is too old |
| 17 | OLD SWV M0 | Solenoid valve (cooling water valve) software version is too old |
| 18 | OLD SWV M1 | Solenoid valve (automatic filling device) software version is too old |
| 19 | OLD SWV M2 | Solenoid valve (constant level device) software version is too old |

| Code | English Edition | Description |
|------|------------------------|--|
| 20 | OLD SWV M3 | Solenoid valve (shut-off valve 1) software version is too old |
| 21 | OLD SWV M4 | Solenoid valve (shut-off valve 2) software version is too old |
| 22 | OLD SWV M5 | High-temperature cooler software version is too old |
| 23 | OLD SWV P0 | Pump 0 software version is too old |
| 24 | OLD SWV P1 | Pump 1 software version is too old |
| 25 | OLD SWV P2 | Pump 2 software version is too old |
| 26 | OLD SWV P3 | Pump 3 software version is too old |
| 27 | OLD SWV S0 | External Pt module software version is too old |
| 28 | OLD SWV EN | Ethernet module software version is too old |
| 29 | OLD SWV EC | EtherCAT module software version is too old |
| 30 | OLD SWV U | Universal module software version is too old |
| 31 | OLD SWV B1 | Operating system 1 (command or base) software version is too old |
| 32 | SWV RESERVED | Reserved for software version XXX is too old |
| 33 | CALIBRATION | Faulty calibration of a temperature probe |
| 34 | STACK ADC OVERFLOW | TaskADC: Stack overflow |
| 35 | STACK CHECK OVERFLOW | TaskCheck: Stack overflow |
| 36 | STACK USB OVERFLOW | TaskUSB: Stack overflow |
| 37 | STACK EN OVERFLOW | TaskEthernet: Stack overflow |
| 38 | STACK CAN OVERFLOW | TaskCan: Stack overflow |
| 39 | STACK CONTROL OVERFLOW | TaskControl: Stack overflow |
| 56 | FREI56 | |

8.4 Safety system warnings



All warnings start with the prefix 1. Two numbers will follow the prefix. These numbers can be found in the following table.

| Code | English Edition | Description |
|------|--------------------|---|
| 01 | CAN OVERFLOW | Overflow at CAN reception |
| 02 | WATCHDOG RESET | Watchdog reset |
| 03 | SAFE MODE | SAFE MODE signal as a warning |
| 04 | NO RESPONSE RTT | No response to relay/Triac test request |
| 05 | BATH LOLEVEL FLOAT | Low level of float (currently level 2) |

| Code | English Edition | Description |
|------|-----------------|---|
| 06 | FREE 5 | |
| 07 | FREE 6 | |
| 08 | INVALID PARA NV | Invalid parameter in the memory |
| 09 | UNKNOWN NODE | Unknown CAN node module connected |
| 10 | OLD SWV R | Control system software version is too old |
| 11 | OLD SWV S | Protection system software version is too old |
| 12 | OLD SWV B | Operating system software version is too old |
| 13 | OLD SWV T | Temperature control system software version is too old |
| 14 | OLD SWV A | Analog module software version is too old |
| 15 | OLD SWV RS232 | RS232 module software version is too old |
| 16 | OLD SWV D | Digital module software version is too old |
| 17 | OLD SWV M0 | Solenoid valve (cooling water valve) software version is too old |
| 18 | OLD SWV M1 | Solenoid valve (automatic filling device) software version is too old |
| 19 | OLD SWV M2 | Solenoid valve (constant level device) software version is too old |
| 20 | OLD SWV M3 | Solenoid valve (shut-off valve 1) software version is too old |
| 21 | OLD SWV M4 | Solenoid valve (shut-off valve 2) software version is too old |
| 22 | OLD SWV M5 | High-temperature cooler software version is too old |
| 23 | OLD SWV P0 | Pump 0 software version is too old |
| 24 | OLD SWV P1 | Pump 1 software version is too old |
| 25 | OLD SWV P2 | Pump 2 software version is too old |
| 26 | OLD SWV P3 | Pump 3 software version is too old |
| 27 | OLD SWV S0 | External Pt module software version is too old |
| 28 | OLD SWV EN | Ethernet module software version is too old |
| 29 | OLD SWV EC | EtherCAT module software version is too old |
| 30 | OLD SWV U | Universal module software version is too old |
| 31 | OLD SWV B1 | Operating system 1 (command or base) software version is too old |
| 32 | SWV RESERVED | Reserved for software version XXX is too old |
| 33 | CAN WARNING | CAN communication issue has occurred |
| 34 | CALIBRATION | Faulty calibration of a temperature probe |
| 56 | FREI56 | |

8.5 SmartCool warnings



All warnings start with the prefix 3. Two numbers will follow the prefix. These numbers can be found in the following table.

| Code | English Edition | Description |
|------|-----------------------------|--|
| 01 | CAN receive overf | Overflow at CAN reception |
| 02 | Watchdog reset | Watchdog reset |
| 03 | Missing SM adaption1 | Perform adaptation cycle |
| 04 | Pressure switch 1 activated | Pressure switch KM1 in cooling circuit triggered |
| 05 | CONDENSER DIRTY | Condenser dirty → clean |
| 06 | KLIXON1 | KM1: to1 is too high, Klixon has most probably triggered |
| 07 | Invalid Parameter | Impermissible parameter in the memory |
| 08 | CAN system | Internal data exchange issue |
| 09 | Unknown module | Unknown module connected |
| 10 | SWV CONTROL OLD | Operating system software version is too old |
| 11 | SWV SAFETY OLD | Protection system software version is too old |
| 13 | SWV COOL OLD | Temperature control system software version is too old |
| 14 | SWV ANALOG OLD | Analog module software version is too old |
| 15 | SWV SERIAL OLD | Serial module software version is too old |
| 16 | SWV CONTACT OLD | Contact module software version is too old |
| 17 | SWV VALVE 0 OLD | Valve module 0 software version is too old |
| 18 | SWV VALVE 1 OLD | Valve module 1 software version is too old |
| 19 | SWV VALVE 2 OLD | Valve module 2 software version is too old |
| 20 | SWV VALVE 3 OLD | Valve module 3 software version is too old |
| 21 | SWV VALVE 4 OLD | Valve module 4 software version is too old |
| 22 | SWV PUMP 0 OLD | Pump module 0 software version is too old |
| 23 | SWV PUMP 1 OLD | Pump module 1 software version is too old |
| 24 | SWV PUMP 2 OLD | Pump module 2 software version is too old |
| 25 | SWV PUMP 3 OLD | Pump module 3 software version is too old |
| 26 | SWV HTC OLD | High-temperature cooler software version is too old |
| 27 | SWV EXT PT OLD | External Pt module software version is too old |
| 28 | SWV ETHERNET OLD | Ethernet module software version is too old |
| 29 | SWV ETHERCAT OLD | EtherCAT module software version is too old |
| 30 | SWV UNIVERSAL | Universal module software version is too old |


| Code | English Edition | Description |
|------|----------------------|--|
| 31 | SWV COMMAND 1 OLD | Operating system 1 (command or base) software version is too old |
| 32 | SWV RESERVED | Reserved for software version XXX is too old |
| 33 | MISSING ADAPT2 | |
| 34 | PRESS SWITCH2 | Pressure switch KM2 has triggered |
| 35 | KLIXON2 | KM2: to1 is too high, Klixon has most probably triggered |
| 36 | SMIN TOO SMALL | to1 is too low in minimum position |
| 37 | VALVE NOT CLOSED | Cooling valve does not close correctly during adaptation cycle |
| 38 | CALIBRATION | Faulty calibration of a temperature probe |
| 39 | VALVE CHANGED | A valve was modified/replaced |
| 40 | WRONG NET FREQUENCY | |
| 41 | WRONG NET VOLTAGE | |
| 42 | NO PRO TYPE | Invalid PRO device type |
| 43 | NO PRO VOLTAGE | Invalid PRO mains voltage setting |
| 44 | KM CURRENT NOT OK | Refrigerating machine frequency incorrect |
| 45 | STACK OVERFLOW CAN | TaskCan: 90 % stack utilization exceeded |
| 46 | STACK OVERFLOW ADC | TaskADC: 90 % stack utilization exceeded |
| 47 | STACK OVERFLOW CHECK | TaskCheck: 90 % stack utilization exceeded |
| 48 | STACK OVERFLOW COOL | TaskCool: 90 % stack utilization exceeded |
| 49 | STACK OVERFLOW FAN | TaskFan: 90 % stack utilization exceeded |
| 50 | RTOS MISC | |
| 51 | KM OFF AT SERV | Refrigerating machine switched off during adaptation/flushing |
| 52 | Free 52 | |
| 53 | Free 53 | |
| 54 | Free 54 | |
| 55 | Free 55 | |
| 56 | Free 56 | |


9 Decommissioning

9.1 General information on decommissioning


Information on decommissioning and course of action if there is a risk of freezing

- Drain the internal cooling water coil on the heating bath thermostat and heating circulation thermostat (both directions suitable) using compressed air or a watertight industrial vacuum cleaner.
- If the device has a refrigerating machine, drain the cooling water circuit on the refrigerating machine (both directions suitable) using compressed air or a watertight industrial vacuum cleaner.
- Drain the pump chamber on the circulation thermostat from the intake side using compressed air or a watertight industrial vacuum cleaner.

| | |
|---|---|
|  NOTICE! Risk of refrigerant escaping from refrigerant circuit | |
| | Device damage |
| | <ul style="list-style-type: none">● Before decommissioning the device or if there is a risk of freezing, drain the refrigerant circuit on the refrigerating machine using compressed air or an industrial vacuum cleaner (watertight). Blow compressed air through the circuit. |

| | |
|---|---|
|  NOTICE! Pump output decreases | |
| | Device damage |
| | <ul style="list-style-type: none">● Before decommissioning the device or if there is a risk of freezing, drain the pump completely from the intake side. Blow compressed air through the circuit. |

The following safety notices are relevant for devices containing natural refrigerant:

| | |
|--|---|
|  WARNING! Risk of refrigerant escaping from refrigerant circuit | |
| | Explosion, fire |
| | <ul style="list-style-type: none">● Before decommissioning the device or if there is a risk of freezing, drain the refrigerant circuit on the refrigerating machine using compressed air or an industrial vacuum cleaner (watertight). Blow compressed air through the circuit. |



Refer to Chapter 9.2 “Changing/draining heat transfer liquid” on page 111 for detailed information on draining the heat transfer liquid.

9.2 Changing/draining heat transfer liquid



WARNING!
Contact with hot or cold heat transfer liquid

Scalding, cold burns

- Bring the heat transfer liquid to room temperature before draining.



WARNING!
Splashing heat transfer liquid

Eye damage

- Always wear suitable safety glasses when working on the device.



Fig. 73: Attaching hose



Observe the regulations for the disposal of used heat transfer liquid.

1. Allow the device and heat transfer liquid to cool or warm up to room temperature.
2. Turn off the device and pull out the mains plug.
3. Attach a hose to the draining nozzle.
4. Place the hose in a suitable container to collect the heat transfer liquid.



It may be necessary to drain the device several times if the filling volume is high.

5. Open the draining tap by turning it counterclockwise.



Drain the bath, external consuming unit, accessories and hoses completely.

6. If necessary, clean or flush out the device (with new heat transfer liquid, for example).



After changing to a different heat transfer liquid, you may have to set new values for the temperature limit, overtemperature switch-off point and/or the controller output limit.

10 Disposal

10.1 Disposing of refrigerant

Disposal of refrigerant must proceed according to regulation 2015/2067/EU in combination with regulation 517/2014/EU.

| | |
|---|--|
| ! NOTICE! Uncontrolled escape of refrigerant | |
| | Environment |
| | <ul style="list-style-type: none">● Never dispose of a cooling circuit that is still pressurized.● Only specialized personnel are permitted to perform disposal work. |

The following safety notice is relevant for devices containing natural refrigerant:

| | |
|--|--|
| ⚠ CAUTION! Uncontrolled escape of refrigerant | |
| | Explosion, fire |
| | <ul style="list-style-type: none">● Never dispose of a cooling circuit that is still pressurized.● Only specialized personnel are permitted to perform disposal work. |

| | |
|----------|---|
| i | <i>The refrigerant type and filling weight are printed on the type plate.</i> |
|----------|---|

10.2 Device disposal



The following applies for EU member states: The device must be disposed of according to Directive 2012/19/EU (WEEE Waste of Electrical and Electronic Equipment).

10.3 Disposing of packaging

The following applies for EU member states: Disposal of the packaging must proceed according to regulation 94/62/EC.

11 Technical data

The information has been conveyed in accordance with DIN 12876.

11.1 General data

Table 15: Base remote control unit

| Specification | Value | Unit |
|--------------------|---------------------------------|--------|
| Display type | OLED monochrome graphic display | --- |
| Display size | 2.7 | Inches |
| | 61 x 30 | mm |
| Display resolution | 128 x 64 | Pixels |
| Display definition | 0.01 | °C |
| Setting resolution | 0.01 | °C |

Table 16: Shared device data

| Specification | Value | Unit |
|--|---|---|
| Installation and use | Indoors | --- |
| Maximum height of installation above sea level | Up to 2,000 | m |
| Air humidity | Maximum relative air humidity 80 % at ambient temperature of 31 °C and up to 40 °C, 50 % with linear decrease | --- |
| Ambient temperature range | 5 – 40 | °C |
| IP protection level | IP 21 | --- |
| Mains voltage fluctuations | up to ±10 % of the mains voltage | |
| Protection class for electrical equipment DIN EN 61 140 (VDE 0140-1) | 1 | --- |
| Class division according to DIN 12 876-1 | III | --- |
| | | FL (suitable for combustible and non-combustible liquids) |
| Bath thermostat temperature stability* | ±0.01 | K |
| Circulating thermostat temperature stability* | ±0.05 | K |
| Storage temperature range | 5 – 40 | °C |
| Transportation temperature range | -20 – 50 | °C |
| | -20 – 43 | °C |
| | -20 – 50 | °C |
| | -20 – 43 | °C |

* Measured value according to standard DIN 12876-2 (12/2001)



The noise level of the various devices was measured according to the guidelines included in DIN EN ISO 11200 and the basic standards cited therein. The measured values correspond to the operating conditions that occur during typical device operation.

Table 17: Heating bath thermostats

| | Unit | P10 | P20 | P30 |
|--|--------|--|--|--|
| Working temperature range | °C | 40 – 250 | 35 – 250 | 30 – 250 |
| Operating temperature range (with external cooling) | °C | -30 – 250 | -30 – 250 | -30 – 250 |
| Device dimensions (W x D) | mm | 310 x 335 | 350 x 475 | 400 x 600 |
| Device height (H), including base | mm | 365 | 365 | 365 |
| Bath opening (W x D) | mm | 240 x 150 | 300 x 290 | 340 x 385 |
| Bath depth (H) | mm | 200 | 200 | 200 |
| Usable depth | mm | 180 | 180 | 180 |
| Filling volume | | | | |
| - Maximum | L | 10.0 | 20.0 | 28.5 |
| - Minimum | L | 5.5 | 11.0 | 15.5 |
| Connecting thread on cooling coil (thermal devices only) | Inches | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal |
| Noise level (1 m) | dB(A) | 49 | 49 | 49 |
| Weight | kg | 13 | 19 | 23 |
| Clearance | | | | |
| - Front | mm | 200 | 200 | 200 |
| - Rear | mm | 200 | 200 | 200 |
| - Right | mm | 200 | 200 | 200 |
| - Left | mm | 200 | 200 | 200 |

Table 18: Cooling bath thermostats

| | Unit | RP 2040 | RP 3035 | RP 2045 | RP 1090 | RP 2090 | RP 10100 |
|-----------------------------------|-------|-----------|-----------|-----------|-----------|-----------|------------|
| *ACC area | °C | -40 – 200 | -35 – 200 | -45 – 200 | -90 – 200 | -90 – 200 | -100 – 200 |
| Device dimensions (W x D) | mm | 400 x 565 | 440 x 600 | 400 x 565 | 440 x 600 | 500 x 600 | 500 x 600 |
| Device height (H), including base | mm | 680 | 680 | 680 | 730 | 730 | 730 |
| Bath opening (W x D) | mm | 300 x 290 | 340 x 375 | 300 x 290 | 240 x 150 | 300 x 290 | 240 x 150 |
| Bath depth (H) | mm | 200 | 200 | 200 | 200 | 200 | 200 |
| Usable depth | mm | 180 | 180 | 180 | 180 | 180 | 180 |
| Filling volume | | | | | | | |
| - Maximum | L | 21.0 | 29.5 | 21.0 | 11.0 | 21.0 | 11.0 |
| - Minimum | L | 12.5 | 17.5 | 12.5 | 6.5 | 12.5 | 6.5 |
| Noise level (1 m) | dB(A) | 52 | 52 | 53 | 54 | 54 | 54 |
| Weight | kg | 54 | 57 | 59 | 88 | 89 | 88 |
| Clearance | | | | | | | |
| - Front | mm | 200 | 200 | 200 | 200 | 200 | 200 |
| - Rear | mm | 200 | 200 | 200 | 200 | 200 | 200 |
| - Right | mm | 200 | 200 | 200 | 200 | 200 | 200 |
| - Left | mm | 200 | 200 | 200 | 200 | 200 | 200 |



*ACC area (Active Cooling Control) according to DIN 12876 is the working temperature range during operation with an active refrigerating machine.

Table 19: Cooling circulation thermostats and heating circulation thermostats

| | Unit | RP 240 E | RP 245 E | RP 250 E | RP 290 E | P 2 E |
|--|--------|------------|------------|------------|------------|--|
| *ACC area/working temperature range | °C | -40 – 200* | -45 – 200* | -50 – 200* | -90 – 200* | 80 – 250 |
| Operating temperature range (heating device with external cooling) | °C | --- | --- | --- | --- | -30 – 250 |
| Device dimensions (W x D) | mm | 300 x 430 | 300 x 430 | 300 x 430 | 390 x 600 | 250 x 365 |
| Device height (H), including base | mm | 675 | 675 | 675 | 685 | 425 |
| Filling volume | | | | | | |
| - Maximum | L | 4.4 | 4.4 | 4.4 | 4.4 | 4.4 |
| - Minimum | L | 2.4 | 2.4 | 2.4 | 2.4 | 2.4 |
| Pump data | | | | | | |
| Maximum conveyance pressure | bar | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |
| Maximum conveyance pull | bar | 0.4 | 0.4 | 0.4 | 0.4 | 0.4 |
| Maximum flow pressure | L/min | 22 | 22 | 22 | 22 | 22 |
| Maximum flow pull | L/min | 20 | 20 | 20 | 20 | 20 |
| Pump connecting thread | mm | M16 x 1 | M16 x 1 | M16 x 1 | M16 x 1 | M16 x 1 |
| Connecting thread on cooling coil (thermal devices only) | Inches | --- | --- | --- | --- | Thread G3/8" external & G1/4" internal |
| Noise level (1 m) | dB(A) | 54 | 54 | 57 | 56 | 47 |
| Weight | kg | 46 | 46 | 47 | 79 | 16 |
| Clearance | | | | | | |
| - Front | mm | 200 | 200 | 200 | 200 | 200 |
| - Rear | mm | 200 | 200 | 200 | 200 | 200 |
| - Right | mm | 200 | 200 | 200 | 200 | 200 |
| - Left | mm | 200 | 200 | 200 | 200 | 200 |



*ACC area (Active Cooling Control) according to DIN 12876 is the working temperature range during operation with an active refrigerating machine.

11.2 Refrigerating machine and cooling water



The devices are operated with partially halogenated and/or natural refrigerant, depending on the device model. The cooling output values measured for partially halogenated refrigerant and natural refrigerant are identical. The designation and refrigerant charge are specified on the device type plate.



The cooling output is measured when the heat transfer liquid reaches a certain temperature. These temperatures are specified in brackets. The ambient temperature for the measurement is 20 °C and ethanol was used as a heat transfer liquid. To measure water-cooled devices, the cooling water temperature is 15 °C and the cooling water differential pressure is 3 bar.



The cooling water must be a minimum of 5 – 10 K cooler than the ambient temperature of the device to ensure efficient cooling.

Table 20: Cooling water data

| Specification | Value |
|--|---|
| Maximum cooling water pressure | 10 bar |
| Minimum differential pressure of cooling water (input - output) Δp | 0 bar |
| Maximum differential pressure of cooling water (input - output) Δp | 3.0 bar |
| Cooling water temperature | 15 °C recommended, 10 to 30 °C permitted (in upper temperature range with reduced cooling output) |
| Diameter of cooling water hoses | 10 mm |



Cooling water hoses

Hoses with an inner diameter of 10 mm are recommended for the nipples supplied with the device.

Table 21: Single-stage refrigerating machine

| | Unit | RP 2040 | RP 3035 | RP 2045 | Pump level |
|-------------------------|------|---------|---------|---------|------------|
| Cooling output at 20 °C | W | 800 | 800 | 1500 | 8 |
| at 10 °C | W | 800 | 800 | 1430 | 8 |
| at 0 °C | W | 800 | 800 | 1170 | 8 |
| at -10 °C | W | 600 | 580 | 840 | 8 |
| at -20 °C | W | 400 | 350 | 520 | 4 |
| at -30 °C | W | 190 | 160 | 280 | 4 |
| at -35 °C | W | 110 | 100 | 200 | 4 |
| at -40 °C | W | 60 | --- | 130 | 4 |
| at -45 °C | W | --- | --- | 70 | 4 |
| at -50 °C | W | --- | --- | --- | --- |

| | Unit | RP 2040 | RP 3035 | RP 2045 | Pump level |
|---|--------|--|--|--|------------|
| Cooling water connection sockets | Inches | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | --- |
| Flow of cooling water with temperature of 15 °C | L/min | 1 bar ⇔ 2.1 | 1 bar ⇔ 2.1 | 1 bar ⇔ 1.3 | --- |

| | Unit | RP 240 E | RP 245 E | RP 250 E | Pump level |
|---|--------|--|--|--|------------|
| Cooling output at 20 °C | W | 600 | 800 | 1500 | 8 |
| at 10 °C | W | 600 | 800 | 1440 | 8 |
| at 0 °C | W | 600 | 800 | 1200 | 8 |
| at -10 °C | W | 410 | 530 | 840 | 8 |
| at -20 °C | W | 240 | 340 | 540 | 4 |
| at -30 °C | W | 120 | 150 | 290 | 4 |
| at -35 °C | W | 70 | 90 | --- | 4 |
| at -40 °C | W | 20 | 40 | 110 | 4 |
| at -45 °C | W | --- | 10* | 40 | 4 |
| at -50 °C | W | --- | --- | 20 | 2 |
| Cooling water connection sockets | Inches | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | --- |
| Flow of cooling water with temperature of 15 °C | L/min | 1 bar ⇔ 2.1 | 1 bar ⇔ 2.1 | 1 bar ⇔ 2.1 | --- |

Table 22: Dual-stage refrigerating machine

Table 22: Dual-stage refrigerating machine

| | Unit | RP 1090 | RP 2090 | RP 10100 | RP 290 E | Pump level |
|-------------------------|------|---------|---------|----------|----------|------------|
| Cooling output at 20 °C | W | 800 | 800 | 400 | 800 | 8 |
| at 10 °C | W | 750 | 710 | 400 | 770 | 8 |
| at 0 °C | W | 720 | 680 | 400 | 740 | 8 |
| at -10 °C | W | 690 | 650 | 400 | 720 | 8 |
| at -20 °C | W | 660 | 620 | 400 | 700 | 4 |
| at -30 °C | W | 630 | 610 | 390 | 680 | 4 |
| at -40 °C | W | 600 | 580 | 370 | 640 | 4 |
| at -50 °C | W | 540 | 520 | 350 | 540 | 4 |
| at -60 °C | W | 370 | 340 | 320 | 390 | 4 |

| | Unit | RP 1090 | RP 2090 | RP 10100 | RP 290 E | Pump level |
|---|--------|--|--|--|--|------------|
| at -70 °C | W | 240 | 180 | 250 | 210 | 4 |
| at -80 °C | W | 110 | 70 | 170 | 90 | 4 |
| at -90 °C | W | 20 | 10 | 60 | 10* | 4 |
| at -100 °C | W | --- | --- | 10 | --- | 4 |
| Cooling water connection sockets | Inches | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | Thread G3/8" external & G1/4" internal | --- |
| Flow of cooling water with temperature of 15 °C | L/min | 1 bar ⇒ 2.1 | 1 bar ⇒ 2.1 | 1 bar ⇒ 2.1 | 1 bar ⇒ 2.1 | --- |

* measured with pump level 2

11.3 Refrigerant and filling weight

Devices containing semi-halogenated refrigerant

The device contains fluorinated greenhouse gases.

Table 23: Single-stage refrigerating machine

| | Unit | RP 2040 | RP 3035 | RP 2045 |
|----------------------------|------|---------|---------|---------|
| Refrigerant | --- | R-404A | R-404A | R-404A |
| Maximum filling weight | kg | 0.25 | 0.25 | 0.3 |
| GWP _(100a) * | --- | 3922 | 3922 | 3922 |
| CO ₂ equivalent | t | 1.0 | 1.0 | 1.2 |

| | Unit | RP 240 E | RP 245 E | RP 250 E |
|----------------------------|------|----------|----------|----------|
| Refrigerant | --- | R-449A | R-449A | R-452A |
| Maximum filling weight | kg | 0.3 | 0.3 | 0.3 |
| GWP _(100a) * | --- | 1397 | 1397 | 2140 |
| CO ₂ equivalent | t | 0.4 | 0.4 | 0.6 |

Devices containing semi-halogenated and natural refrigerant

The device contains fluorinated greenhouse gases.

Table 24: 2-stage refrigerating machine

| | Unit | RP 1090 | RP 2090 | RP 10100 | RP 290 E |
|------------------------------------|------|---------|---------|----------|----------|
| Refrigerant (1st stage) | --- | R-404A | R-404A | R-404A | R-452A |
| Maximum filling weight (1st stage) | kg | 0.26 | 0.26 | 0.22 | 0.3 |

| | Unit | RP 1090 | RP 2090 | RP 10100 | RP 290 E |
|------------------------------------|------|---------|---------|----------|----------|
| GWP _(100a) * | --- | 3922 | 3922 | 3922 | 2140 |
| CO ₂ equivalent | t | 1.0 | 1.0 | 0.9 | 0.6 |
| Refrigerant (2nd stage) | --- | R-170 | R-170 | R-1150 | R-170 |
| Maximum filling weight (2nd stage) | kg | 0.08 | 0.08 | 0.06 | 0.07 |
| GWP _(100a) * | --- | 3 | 3 | 3 | 3 |

Devices containing natural refrigerant

Table 25: Single-stage refrigerating machine

| | Unit | RP 2040 | RP 3035 | RP 2045 |
|-------------------------|------|---------|---------|---------|
| Natural refrigerant | --- | R-290 | R-290 | R-290 |
| Maximum filling weight | kg | 0.099 | 0.099 | 0.149 |
| GWP _(100a) * | --- | 3 | 3 | 3 |

| | Unit | RP 240 E | RP 245 E | RP 250 E |
|-------------------------|------|----------|----------|----------|
| Natural refrigerant | --- | R-290 | R-290 | R-290 |
| Maximum filling weight | kg | 0.12 | 0.12 | 0.14 |
| GWP _(100a) * | --- | 3 | 3 | 3 |

Devices containing natural refrigerant

Table 26: 2-stage refrigerating machine

| | Unit | RP 1090 | RP 2090 | RP 10100 | RP 290 E |
|------------------------------------|------|---------|---------|----------|----------|
| Refrigerant (1st stage) | --- | R-290 | R-290 | R-290 | R-290 |
| Maximum filling weight (1st stage) | kg | 0.11 | 0.11 | 0.099 | 0.12 |
| GWP _(100a) * | --- | 3 | 3 | 3 | 3 |
| Refrigerant (2nd stage) | --- | R-170 | R-170 | R-1150 | R-170 |
| Maximum filling weight (2nd stage) | kg | 0.08 | 0.08 | 0.06 | 0.07 |
| GWP _(100a) * | --- | 3 | 3 | 3 | 3 |



Global Warming Potential (GWP), CO₂ comparison = 1.0

* Time frame 100 years - according to IPCC IV

11.4 Maximum current consumption and heating output



*The maximum current consumption may be limited in the factory, depending on the mains cable supplied ↪ Chapter 5.11.5 “Limiting the current consumption” on page 76.

Table 27: Heating bath thermostat and heating circulation thermostat

| Power supply | Current consumption setting* | Heating output in kW | | | |
|---------------------|------------------------------|----------------------|-----------|-----------|-----------|
| | | P 10 | P 20 | P 30 | P 2 E |
| 200-230 V; 50/60 Hz | 12 A | --- | --- | --- | 1.9 – 2.5 |
| 200-230 V; 50/60 Hz | 13 A | 2.6 – 3.0 | 2.6 – 3.0 | 2.6 – 3.0 | --- |
| 200-230 V; 50/60 Hz | 15 A | 2.7 – 3.4 | 2.7 – 3.4 | 2.7 – 3.4 | --- |
| 200-230 V; 50/60 Hz | 16 A | 2.7 – 3.6 | 2.7 – 3.6 | 2.7 – 3.6 | --- |
| 100-120 V; 50/60 Hz | 16 A | 1.3 – 1.9 | 1.3 – 1.9 | 1.3 – 1.9 | 1.3 – 1.8 |

Table 28: Cooling bath thermostats

| Power supply | Current consumption setting* | Heating output in kW | | | | | |
|------------------|------------------------------|----------------------|-----------|-----------|-----------|-----------|-----------|
| | | RP 2040 | RP 2045 | RP 3035 | RP 1090 | RP 2090 | RP 10100 |
| 230 V; 50 Hz | 13 A | 3.0 | 3.0 | 3.0 | 3.0 | 3.0 | 3.0 |
| 230 V; 50 Hz | 15 A | 3.4 | 3.4 | 3.4 | 3.4 | 3.4 | 3.4 |
| 230 V; 50 Hz | 16 A | 3.6 | 3.6 | 3.6 | 3.6 | 3.6 | 3.6 |
| 208-220 V; 60 Hz | 13 A | 2.7 – 2.9 | 2.7 – 2.9 | 2.7 – 2.9 | 2.7 – 2.9 | 2.7 – 2.9 | 2.7 – 2.9 |
| 208-220 V; 60 Hz | 16 A | 2.9 – 3.3 | 2.9 – 3.3 | 2.9 – 3.3 | 2.9 – 3.3 | 2.9 – 3.3 | 2.9 – 3.3 |
| 200 V; 50/60 Hz | 16 A | 2.7 | 2.7 | 2.7 | 2.7 | 2.7 | 2.7 |
| 120 V; 60 Hz | 16 A | 1.9 | --- | 1.9 | --- | --- | --- |
| 100 V; 50/60 Hz | 15 A | 1.3 | --- | 1.3 | --- | --- | --- |
| 100 V; 50/60 Hz | 16 A | 1.3 | --- | 1.3 | --- | --- | --- |

Table 29: Cooling circulation thermostats

| Power supply | Current consumption setting* | Heating output in kW | | | |
|------------------|------------------------------|----------------------|-----------|-----------|-----------|
| | | RP 240 E | RP 245 E | RP 250 E | RP 290 E |
| 230 V; 50 Hz | 13 | 2.5 | 2.5 | --- | --- |
| 230 V; 50 Hz | 15 | 2.5 | 2.5 | --- | --- |
| 230 V; 50 Hz | 16 | 2.5 | 2.5 | 2.5 | 2.5 |
| 208-220 V; 60 Hz | 13 | 2.1 – 2.3 | 2.1 – 2.3 | --- | --- |
| 208-220 V; 60 Hz | 16 | 2.1 – 2.3 | 2.1 – 2.3 | 2.0 – 2.3 | 2.0 – 2.3 |
| 200 V; 50/60 Hz | 16 | 1.9 | 1.9 | 1.9 | 1.9 |
| 120 V; 60 Hz | 16 | 1.8 | 1.8 | --- | --- |
| 100 V; 50/60 Hz | 15 | 1.3 | 1.3 | --- | --- |
| 100 V; 50/60 Hz | 16 | 1.3 | 1.3 | --- | --- |

12 Accessories

The following optional accessories are available for PRO devices.

Table 30: Module bay 51 mm x 27 mm

| Accessory | Cat. No. |
|--|----------|
| Analog interface module | LRZ 912 |
| RS232/485 interface module | LRZ 913 |
| Contact interface module with 1 input and 1 output | LRZ 914 |
| Contact interface module with 3 inputs and 3 outputs | LRZ 915 |
| Profibus interface module | LRZ 917 |
| Ethernet/USB interface module | LRZ 921 |
| EtherCAT interface module, M8 socket connection | LRZ 922 |
| EtherCAT interface module, RJ45 socket connection | LRZ 923 |

Table 31: Connecting plug

| Accessory | Cat. No. |
|--|----------|
| External temperature probe with socket and shielded connection cable | ETP 059 |
| Coupling connector, 6-pin for analog inputs/outputs | EQS 057 |
| Connecting plug SUB-D, 9-pin | EQM 042 |
| RS232 cable (length: 2 m) for PC | EKS 037 |
| RS232 cable (length: 5 m) for PC | EKS 057 |
| 3-pin coupling connector for contact input | EQS 048 |
| 3-pin coupling socket for contact output | EQD 047 |

| Accessory | Suitable for | Cat. No. |
|-----------------------------------|--------------|----------|
| Command Touch remote control unit | All devices | LRT 923 |

13 General

13.1 Copyright

This manual is protected by copyright and only meant for internal use by purchasers.

The relinquishment of this manual to third parties, copying in any way whatsoever - even just excerpts - and the utilization and/or conveyance of its content are not allowed without written approval from the manufacturer.

Violation of this may obligate the violator to the payment of damages. Other claims reserved.

13.2 Technical changes

The manufacturer reserves the right to make technical modifications to the device.

13.3 Warranty conditions

LAUDA grants a standard warranty of one year on all devices.

13.4 Contact LAUDA

Contact LAUDA Service Constant temperature equipment in the following cases:

- For device errors
- For technical questions concerning the device
- To order replacement parts

Contact our Sales Department for application-specific questions.

Contact information

LAUDA Service Constant temperature equipment

Phone: +49 (0)9343 503 350

Fax: +49 (0)9343 503 283

Email: service@lauda.de

13.5 EU conformity



The device complies with the basic health and safety requirements outline in the Directives listed below.

- Machinery Directive 2006/42/EC
- EMC Directive 2014/30/EU

LAUDA DR. R. WOBSE GMBH & CO. KG - Pfarrstraße 41/43 - 97922 Lauda-Königshofen - Germany



The device does not fall under Pressure Equipment Directive 2014/68/EU because the device is only classified as high as Category 1 and is covered by the Machinery Directive.

14 Glossary

| | |
|---|---|
| Auto IP | Auto IP is a standardized procedure where two participants agree on the same network configuration. |
| DHCP Client (Dynamic Host Configuration Protocol Client) | A DHCP client facilitates the automatic integration of an Ethernet interface in an existing network. As a result, the interface does not have to be manually integrated in the existing network. |
| DNS server (Domain Name Service Server) | The Domain Name Service is a database where mainly information on names and IP addresses of the computer are stored. A DNS can, for example, disperse a web address or URL (Uniform Resource Locator) to an IP address. The Ethernet interface specifies the IP address of the DNS server present in the connected network. |
| Gateway | Various networks are connected with one another via the gateway. Here, an IP address is given that can be used to reach a gateway in a local network. |
| IP address (Internet Protocol Address) | Each device within a data network requires an address, so that it can be clearly identified. This applies both for small home networks and the Internet. This is the only way to ensure that the data flow is received by the correct device. When an Internet page is opened, the browser always transfers the IP address of your device as well. This is the only way that the web server can know where to send the required data packet. The Internet Protocol (IP) is a widely adopted network standard that stipulates how information can be exchanged. |
| IP version | Provides information about the Internet standard: IPv4 or IPv6. A well-known example of an IP address is 192.168.0.1. This address is structured according to the IPv4 standard: Four numbers between 0 and 255, whereby a period separates the numbers from one another. However, this system only allows a limited number of combinations, which is why there are IP addresses structured according to the standard in version 6 (IPv6). They consist of eight blocks of characters that can contain both numbers and letters as shown in this example: fe80:0010:0000:0000:0000:0000:0000:0001. Because this can seem rather confusing, a long string of zeros can be replaced by a colon. The IPv6 address from the example would therefore appear in a shortened form as follows: fe80:0010::1. |
| Local IP address | The local IP address is an address for the Ethernet interface in the local network. The Ethernet interface in the local network can be reached using this address. If the DHCP client is deactivated, the local IP address, as well as the local mask, gateway and DNS server, must be manually configured. For manual configuration start by contacting your IT department. |
| Local mask | Local (subnet) masks are used to flexibly adapt the rigid class division of IP addresses in networks and computers to actual conditions. |
| MAC (Media Access Control) | Media access control is a hardware address unique worldwide that can be used to clearly identify the device in an Ethernet network. |
| NTP (Network Time Protocol) | Network time protocol is a standard for synchronizing the time and date in networks. |
| Port | Port is a number that is used to establish a connection between two network participants. Port is a part of the network address. The port for the Ethernet interface can be used from the approved "dynamic ports" range. This lies between 49152 and 65535. |

Process Interface

A process interface on the LAUDA constant temperature equipment is the interface that makes it possible to control or monitor the constant temperature equipment via Ethernet using LAUDA interface command sets.

TCP (Transmission Control Protocol)

This network protocol define how data is exchanged between network components.

15 Index

A

| | |
|--|------------|
| Accessories | |
| In series | 15 |
| Modules | 123 |
| Accessory | 123 |
| Adjusting the brightness (display) | 75 |
| Adjusting the display brightness | 75 |
| Adjusting the volume (signal tone) | 74 |
| Adjustment time | 87, 89, 90 |
| Air-cooled | |
| Cleaning condenser | 99 |
| Alarm | 104 |
| Codes | 104 |
| Alarms | 104 |
| Amplification factor | 90 |
| Attenuation time | 87, 89, 90 |
| Autostart | |
| Activating | 75 |
| Deactivating | 75 |

B

| | |
|---|--------|
| Base | |
| Menu structure | 69 |
| Bath cover (illustration) | 17 |
| Bath draining nozzle (illustration) | 17, 19 |
| Bath thermostat | |
| Structure | 17 |
| Button | |
| Release | 23 |

C

| | |
|--------------------------------------|-----|
| Calibrate (actual temperature) | |
| Determine | 93 |
| Calibration in the factory | 93 |
| Changing | |
| Signal tones | 74 |
| Checking | |
| Heat transfer liquid | 101 |
| Low-level protection | 102 |
| Overtemperature protection | 101 |

| | |
|---|--------|
| Tmax | 101 |
| Circulation thermostat | |
| Connecting an external consuming unit | 53 |
| Hoses | 51 |
| Setting up | 50 |
| Cleaning | 98 |
| CO2 equivalent | 119 |
| Code | |
| Warnings (control system) | 105 |
| Warnings (safety system) | 106 |
| Warnings (SmartCool) | 108 |
| Compressor | 25 |
| Condenser | |
| Cleaning (air-cooled) | 99 |
| Cleaning (water-cooled) | 100 |
| Conformity (EU) | 124 |
| Connecting an external consuming unit | 53 |
| Control | 36 |
| Defining the controller output limit | 80 |
| Warnings | 105 |
| Control menu | 91 |
| Control parameters | |
| Access | 91 |
| Adapting (external) | 92 |
| External (overview) | 90 |
| Internal (overview) | 89 |
| Modifying (internal) | 91 |
| Control station | 36 |
| Cooling coil | 24 |
| Cooling coil connection socket (illustration) | 17 |
| Cooling water | |
| Connecting | 57 |
| Requirements | 55 |
| Copyright | 124 |
| Correction limitation | 87, 90 |
| Cracking | 80 |
| Cursor buttons (illustration) | 66 |
| D | |
| Defining the language (display) | 76 |

| | | | |
|--|---------|---|------------|
| Defining the menu language | 76 | External control | |
| Descaling | 100 | activation | 80 |
| Device | | Defining the set point offset | 81 |
| Cleaning | 98 | F | |
| Cleaning condenser (air-cooled) | 99 | Factory calibration | 93 |
| Decontamination | 98 | Fault | 104 |
| Descaling (water-cooled) | 100 | Feet (illustration) | 19 |
| Displaying serial numbers | 96 | Filling | 61 |
| Disposal (packaging) | 112 | Filling weight | 119 |
| Disposal (refrigerant) | 112 | Flushing | 64, 111 |
| Draining | 64, 111 | Front panel (illustration) | 19 |
| Draining condenser (water-cooled) | 101 | G | |
| Filling | 61 | Grip (illustration) | 19 |
| Installation | 31 | H | |
| Read out memory | 95 | Heat discharge | 26 |
| Switching on | 66 | Heat transfer liquid | |
| Unpacking | 15 | Checking | 101 |
| Viewing data | 95 | Flushing | 64, 111 |
| DIN EN 378-1 | 10 | Removal | 64, 111 |
| Dirt trap | 99 | Heating output | |
| Display | 75 | reduction | 80 |
| Display buttons | | Hold-back time | 87, 89, 90 |
| Operation | 66 | Hoses | 51 |
| Displaying serial numbers (device) | 96 | Hybrid | 26 |
| Disposal | | HyperTerminal | 40 |
| Packaging | 112 | I | |
| Refrigerant | 112 | Immunity | 8 |
| Disposing of refrigerant | 112 | Input button (illustration) | 66 |
| Draining | | Installation (device) | 31 |
| Condenser (water-cooled) | 101 | Installation location | 31 |
| Device | 64, 111 | Intended use | 9 |
| E | | Interface | |
| Emissions class | 8 | Description | 27 |
| Error | 104 | Overview | 27 |
| Modules | 49 | Interface module | |
| Read out memory | 95 | Installing | 31 |
| Establishing a mains connection | 65 | Internal control | |
| Establishing a power supply | 65 | activation | 81 |
| EU conformity | 124 | | |
| Evaporator | 25 | | |
| Expansion | 25 | | |

| | | | |
|--|--------|---|------------|
| K | | Power failure (operating mode) | 75 |
| Key lock | 67 | Program | |
| Kpe | 90 | Ending | 85 |
| | | Example | 82 |
| | | Interrupting | 85 |
| | | Starting | 85 |
| L | | Program optimization | |
| LAUDA Service Constant temperature equipment | | Description | 82 |
| Address | 124 | Prop_E | 90 |
| Contact | 124 | Proportional range | 87, 89, 90 |
| Limit values (temperature) | | Protective equipment (personal, overview) | 11, 12 |
| Setting | 70 | Pump | |
| Low-level protection | | Selecting the flow rate level | 79 |
| Checking | 102 | Selecting the level | 79 |
| Definition | 12 | Selecting the output level | 79 |
| | | SteadyFlow function | 23 |
| M | | Pump nozzle (illustration) | 19 |
| Machinery Directive | 124 | R | |
| Maintenance | | Racks | 50 |
| Intervals | 98 | Reading out memory (error) | 95 |
| Maximum temperature | 101 | Refrigerant | |
| Menu structure | | Combustible | 10 |
| Base | 69 | Filling weight | 119 |
| Modules | | Fluorinated | 10 |
| Accessories | 123 | Refrigerating machine | |
| Monitor | 36 | Function | 25 |
| N | | Release | 23 |
| N2 | 26 | Remote control unit (illustration) | 17 |
| Nitrogen | 26 | Rising platforms | 50 |
| Connection | 22 | Risk of freezing | 110 |
| O | | RS 485 module | |
| Offset (actual temperature) | | Connecting | 34 |
| Calibrate | 93 | S | |
| Overtemperature protection | | Safety notice | |
| Checking | 101 | General | 7 |
| Definition | 12 | Safety system (warnings) | 106 |
| Setting | 69 | Segment | |
| P | | Start | 83 |
| Packaging | | Service (LAUDA, Constant temperature equipment) | 124 |
| Disposal | 112 | Setting the current consumption | 76 |
| Personal protective equipment (overview) | 11, 12 | | |
| Platforms | 50 | | |

| | |
|---|--------|
| Signal tone (adjusting) | 74 |
| SmartCool (warnings) | 108 |
| Softkey (illustration) | 66 |
| Software version | 96 |
| Standby | |
| Activating | 79 |
| Deactivating | 79 |
| Start | |
| Segment | 83 |
| SteadyFlow function | 23 |
| Stirrer | |
| Selecting the level | 79 |
| Switching on | 66 |
| T | |
| Td | 87, 89 |
| Tde | 90 |
| Temperature limits | |
| Setting | 70 |
| Temperature target value | 71 |
| Terminal program | 40 |
| Tih, Til | 70 |
| Til, Tih | 70 |
| Time period | 43 |
| Tmax | |
| Checking | 101 |
| Position | 23 |
| Setting | 69 |
| Tn | 87, 89 |
| Tne | 90 |
| Tv | 87, 89 |
| Tve | 90 |
| Type plate | 29 |
| Device (illustration) | 17, 19 |
| U | |
| Unpacking | 15 |
| USB | 28 |
| V | |
| Ventilation grid (illustration) | 19 |
| Version (software) | 96 |
| Viewing configuration data (device) | 95 |

| | |
|--|--------|
| W | |
| Warning | 104 |
| Control system | 105 |
| Safety system | 106 |
| SmartCool | 108 |
| Warranty | 124 |
| Water cooling | |
| Draining | 110 |
| Water-cooled | |
| Connection socket (illustration) | 19 |
| Draining water-cooled condenser | 101 |
| X | |
| Xp | 87, 89 |
| Xpf | 90 |

An / To / A:

LAUDA Dr. R. Wobser • LAUDA Service Center • Fax: +49 (0) 9343 - 503-222

Von / From / De :

Firma / Company / Entreprise: _____

Straße / Street / Rue: _____

Ort / City / Ville: _____

Tel.: _____

Fax: _____

Betreiber / Responsible person / Personne responsable: _____

Hiermit bestätigen wir, daß nachfolgend aufgeführtes LAUDA-Gerät (Daten vom Typenschild):

We herewith confirm that the following LAUDA-equipment (see label):

Par la présente nous confirmons que l'appareil LAUDA (voir plaque signalétique):

| Typ / Type / Type : | Serien-Nr. / Serial no. / No. de série: |
|---------------------|---|
| | |

mit folgendem Medium betrieben wurde

was used with the below mentioned media

a été utilisé avec le liquide suivant

Darüber hinaus bestätigen wir, daß das oben aufgeführte Gerät sorgfältig gereinigt wurde, die Anschlüsse verschlossen sind, und sich weder giftige, aggressive, radioaktive noch andere gefährliche Medien in dem Gerät befinden.

Additionally we confirm that the above mentioned equipment has been cleaned, that all connectors are closed and that there are no poisonous, aggressive, radioactive or other dangerous media inside the equipment.

D'autre part, nous confirmons que l'appareil mentionné ci-dessus a été nettoyé correctement, que les tubulures sont fermées et qu'il n'y a aucun produit toxique, agressif, radioactif ou autre produit nocif ou dangereux dans la cuve.

| Stempel Seal / Cachet. | Datum Date / Date | Betreiber Responsible person / Personne responsable |
|---------------------------|----------------------|--|
| | | |

Formblatt / Form / Formulaire:

Unbedenk.doc

Erstellt / published / établi:

LSC

Änd.-Stand / config-level / Version:

0.1

Datum / date:

30.10.1998

LAUDA DR. R. WOBSE GmbH & Co. KG

Pfarrstraße 41/43

D - 97922 Lauda-Königshofen

Internet: <http://www.lauda.de>

Tel: +49 (0)9343 / 503-0

Fax: +49 (0)9343 / 503-222

E-mail: info@lauda.de

LAUDA DR. R. WOBSE GMBH & CO. KG
Pfarrstraße 41/43 ° 97922 Lauda-Königshofen ° Germany
Tel.: +49 (0)9343 503-0 ° Fax: +49 (0)9343 503-222
E-mail: info@lauda.de ° Internet: www.lauda.de